

10" IN-LINE / MID DRIVE (CE) PORTABLE AUGER

OWNER'S & OPERATOR'S MANUAL

Effective October 29, 2007

Publication No. 1031874

THIS MANUAL IS FOR UNITS WITH SERIAL NUMBERS OF 920939 OR HIGHER.



Hutchinson/Mayrath

A Division of **GLOBAL** Industries, Inc.

P.O. Box 629 • 514 W. Crawford • Clay Center, KS 67432
Phone 785-632-2161 • 1-800-523-6993 • FAX 785-632-5964



Hutchinson/Mayrath

A Division of **GLOBAL Industries, Inc.**

POLICIES AND PROCEDURES

- PRICES:** Prices in effect at time of shipment will apply. Prices are subject to change without notice. All prices are F.O.B. Clay Center, Kansas. Orders shipped from locations other than Clay Center, Kansas will be subject to additional charges, such as back freight and/or additional freight.
- SERVICE CHARGE:** A service charge will be assessed on all past due balances as permitted by state law not to exceed 1-1/2% per month.
- MINIMUM ORDER:** Processing and handling costs necessitate a minimum charge of \$15.00 net on all orders.
- BACK ORDERS:** Back orders will be shipped as they become available. Contact Hutchinson/Mayrath Customer Service for alternative shipping options or if cancellation is desired.
- DAMAGED GOODS:** It is the consignee's responsibility to check all shipments thoroughly upon receipt of goods. If any damage is discovered, it must be noted on the freight bill of lading before signing. The consignee must make necessary claims against the respective freight line. All damage claims must be submitted within 30 days of delivery receipt.
- SHORTAGES:** All shortages must be noted at time of delivery receipt. Shortages must be noted on the freight bill of lading before signing. Hutchinson/Mayrath must be advised of all concealed shortages upon discovery. Once notified of concealed shortages Hutchinson/Mayrath will advise corrective action to be taken.
- RETURN OF GOODS:** All returns must be approved by Hutchinson/Mayrath prior to shipment. All return requests will be issued a return authorization number. **NO RETURNS WILL BE ACCEPTED WITHOUT A RETURN AUTHORIZATION NUMBER AND PRIOR AUTHORIZATION FROM THE FACTORY.** All returns must be shipped prepaid. A 15% restocking charge will be applied to all returned merchandise. Custom Products may not be returned for credit. Only current products in new and salable condition may be returned. No safety devices may be returned for credit.
- MODIFICATIONS:** It is the policy of Hutchinson/Mayrath to improve its product whenever possible and practical to do so. We reserve the right to make changes, improvements and modifications at any time without incurring the obligation to make such changes, improvements and modifications on any equipment sold previously.
- LIMITED WARRANTY:**
- For a period of (1) year after receipt of goods by the original consumer buyer, Hutchinson/Mayrath will supply free of charge replacement parts for parts that prove defective in workmanship or material. Defective parts must be returned freight prepaid to a specified Hutchinson/Mayrath location. Only Hutchinson/Mayrath original repair parts may be used for warranty repairs.
 - This limited warranty does not extend to parts designed to wear in normal operation and be replaced periodically; or to damage caused by negligence, accident, abuse or improper installation or operation.
 - GOODS NOT MANUFACTURED BY HUTCHINSON/MAYRATH CARRY ONLY THE MANUFACTURER'S WARRANTY.**
 - THIS UNDERTAKING IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**
- FAILURE TO FOLLOW THE INSTRUCTIONS CONTAINED IN THE OWNER'S & OPERATOR'S MANUALS AND THE ITEMS LISTED BELOW WILL RESULT IN THE VOIDING OF THIS LIMITED WARRANTY.**
- Improper assembly, including failure to properly install all safety equipment.
 - Improper installation (power & wiring included).
 - Unauthorized alterations of goods.
 - Goods operated when obviously in need of repair.
 - Use of unauthorized repair parts.
 - Irresponsible operation.
 - Used to handle materials other than free flowing, non-abrasive and dry materials, as intended.
 - Damaged through abusive use or accident.
- LIMITATION OF LIABILITY:** BUYER AGREES THAT IN NO EVENT SHALL HUTCHINSON/MAYRATH HAVE LIABILITY FOR DIRECT DAMAGES IN EXCESS OF THE CONTRACT PRICE OF THE GOODS IN RESPECT OF WHICH CLAIM IS MADE. BUYER FURTHER AGREES THAT IN NO EVENT SHALL HUTCHINSON/MAYRATH ON ANY CLAIM OF ANY KIND HAVE LIABILITY FOR LOSS OF USE, LOSS OF PROFITS, OR FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

GENERAL SAFETY STATEMENT

This manual was written with the safety of the operator and others who work with the equipment as our prime concern. The instructions presented will help the reader learn SAFE day to day work practices. We want you as our partner in safety.


It is your responsibility as an owner, operator or supervisor to know what specific safety requirements and precautions exist and to make these known to all other personnel working with the equipment or in the area, so that they too may safely perform their duties and avoid any potentially hazardous situations.

Please remember safety equipment provides important protection for persons around a grain handling system that is in operation. Be sure that ALL safety shields and protection devices are installed and properly maintained. If any shields or guards are damaged or missing, contact your dealer to obtain the correct items.

Avoid any alterations of the equipment. Such alterations may create a dangerous situation where serious injury or death may occur.

SAFETY ALERT SYMBOL

The symbol shown below is used to call your attention to instructions concerning your personal safety. Watch this symbol - it points out important safety precautions. It means "ATTENTION! Become alert! Your personal safety is involved!" Read the message that follows and be alert to the possibility of personal injury or death.



BE ALERT! YOUR SAFETY IS INVOLVED.

WARNING



Anyone who will operate or work around this machine shall first read this manual! This manual must be delivered with the equipment to its owner. Failure to read this manual and its safety instructions is a misuse of the equipment.

TABLE OF CONTENTS

General Safety Statements	1
Safety Symbol	1
Machine Inspection	3
HITCHING TO TRACTOR INSTRUCTIONS	4
Hitch Safety Chain Installation	4
Hydraulic Components for Hydraulic Lift Undercarriage	4
TRANSPORTING AUGER	5
PLACEMENT OF AUGER	6
Step 1 - Locate the Auger	6
Step 2 - Raising the Auger	6
Step 3 - Back into Working Position	6
DESIGNATED WORK AREA	7
Rules for Safe Work Area	7
Work Area Diagram	7
OPERATING PROCEDURES	8-12
Start-up and Break-in Information	8
Direct PTO Drive Information	8-9
Top Mounted Electric Motor Drive Information	10-11
Operating Capacities	11
Shutdown	11
Lockout	12
RELOCATION OF AUGER	12
LUBRICATION AND MAINTENANCE	13-14
Gearbox	13
PTO Driveline	13
Bearing	13
Hydraulic Cylinder	14
Hydraulic Hose	14
Belt Adjustment	14
Winch	14
TROUBLE SHOOTING	15
ASSEMBLY INSTRUCTIONS	16-44
PARTS LIST	P-1 thru P-17

SERIAL NUMBER

To ensure efficient and prompt service, please furnish us with the model and serial number of your auger in all correspondence or other contact. The serial plate is located on the left side of the drive housing on the tube.

RIGHT AND LEFT DESIGNATION

When determining which is the left or right hand side of the unit, it is as if a person were standing at the intake end and looking toward the discharge end.

MACHINE INSPECTION

After delivery of your new auger and/or completion of assembly and before each use, inspection of the machine is mandatory. Use the assembly instructions in this manual as a reference to determine that the auger is assembled properly. This inspection should include, but not be limited to:

1. Check to see that all guards listed in the assembly instructions are in place, secured and functional.
The shields on the input drive line must rotate easily.
2. Check all safety signs and replace any that are worn, missing or illegible. The safety signs are listed on page P1 and P2. Safety signs may be obtained from your dealer or ordered from the factory.
3. On Manual Lift Models - Check winch and cable for security and operation. There should be at least three complete wraps of cable around winch drum in full down position. Cable anchor on winch drum must be tight.
On Hydraulic Lift Models - Check the hydraulic hose and all the fitting connections to see if they are tight and not leaking hydraulic oil.
4. Are all fasteners tight?
5. Are belts properly adjusted? (See Maintenance Section.)
6. Check oil level in gearbox. (See Maintenance Section.)

TRACTOR REQUIREMENTS

This 10" auger was designed to use a tractor with the following specifications:

1. 540 PRM Power Take Off
2. One hydraulic control circuit for lifting the main auger. (See chart for minimum pressure.)


	10" x 32'	10" x 42'	10" x 52'	10" x 62'	10" x 72'
Tractor Hydraulic for Auger Lift	N/A	N/A	10,500 kpa	10,500 kpa	10,500 kpa
Approximate PTO Power	22 kw	30 kw	37 kw	45 kw	52 kw

HITCHING TO TRACTOR INSTRUCTIONS

1. Never stand between tractor and machine when hitching unless all controls are in neutral and the brakes locked.
2. Never raise the intake end higher than is necessary to attach to the tractor. Weight transfers rapidly to the head end when the intake is raised. **NOTE:** Empty machine before moving to prevent upending. It may be necessary when lifting the intake for hitching or unhitching to use assistance in the lifting process. The intake weight may be greater than what one person can comfortably lift. Use of a portable jack is recommended when necessary. A recommended lifting point is where the hitch emerges from the intake. Be sure the auger wheels are chocked when lifting with a portable jack.
3. An auxiliary attachment system (safety chain) is required to retain the connection between towing and towed machines in the event of separation of the primary attachment system.
4. Make certain the hitch pin is securely attached and an alternate hitch safety chain is secured to the auger and the tractor. Check to see that the hitch is securely attached to the auger.


The safety chain should be routed through the intake safety screen and around the tow bar at the lower end of the intake. Then route the chain through the chain support on the hitch pipe and anchor chain to tractor.

A clevis or intermediate chain support should be fastened to the tractor drawbar no farther than 6" from the hitch pin.



5. On Hydraulic Lift Models - connect the hydraulic hose to tractor. A 1/2" female pipe thread tractor fitting (not furnished) is required to fit the shut-off valve on the end of the hose.

WARNING: Keep all hydraulic lines away from moving parts.



CAUTION: Do not connect or disconnect hydraulic components when there is pressure within the system. Hydraulic systems are highly pressurized. Escaping hydraulic oil, even an invisible pinhole leak, can penetrate body tissues and cause serious injury. Use a piece of wood or cardboard when looking for leaks. Never use the hands or other parts of the body. When reassembling, make absolutely certain that all connections are tight. If injured by hydraulic oil escaping under pressure, see a doctor immediately. Serious infection or reaction may occur if medical attention is not received at once.


TRANSPORTING AUGERS

Moving your portable auger requires careful planning. A route plan should be considered beforehand to avoid dangerous obstacles and loss of time.

TRANSPORT: Move the auger with a tractor to or from the work area. A pick-up truck or other suitable vehicle may be used for transporting the auger over greater distances.

Follow these steps when transporting auger:

1. Always transport your auger in the full-down position.
2. On Manual Lift Models - Be sure there is slight tension on the winch cable (shown below).
3. On Hydraulic Lift Models - The hydraulic shut-off valve must be closed.



10" AUGER LENGTH



	32'	42'	52'	62'	72'
*TRANSPORT HEIGHT (Manual Lift Model)	2.7 m to 3 m	3 m to 3.3 m	3.3 m to 3.6 m	3.8 m to 4.1 m	3.9 m to 4.2 m
(Hydraulic Lift Model)	N/A	N/A	3.4 m to 3.7 m	3.8 m to 4 m	3.8 m to 4 m

***IMPORTANT:** Overall transport height is with the auger fully lowered and the intake on the ground. When the auger is attached to a towing vehicle, these heights will be approximately .3 m less.

Do not transport the auger at speeds in excess of 20 MPH and comply with your state and local regulations governing marking, towing and maximum width. Observe safe driving and operation practices.



Be alert to overhead obstructions and electrical wires. Failure to do so may result in electrocution. Lower auger well below level of power lines before moving. Maintain at least 3 meters of clearance. See above chart showing the height of each portable auger in the lowered transport position. Check the chart to determine the height of your auger.



**WHEN MOVING AUGER
HAZARD AREA - KEEP OUT**

PLACEMENT OF AUGER

Placement - Move auger slowly toward working position with a tractor.



Step 1

Locate the auger as close as possible to the bin or other structure. Move auger slowly towards working position with a tractor - not by hand. When moving the auger towards the working position, leave adequate room for convenient path for loaded vehicles to reach the auger intake area.

1. Place the auger on level surface. The wheels must be allowed to roll freely when raising. Be sure this area is clear of any obstructions.
2. On Hydraulic Lift Undercarriage Models - Open hydraulic shut-off valve.



Make certain everyone is clear of the work area when moving the auger. To prevent tip-over when backing, avoid rolling over any obstructions. Also avoid moving the auger at right angles to a slope. If the auger must set on a slope, approach the bin uphill.

Make sure entire area above auger and in line of travel is clear of overhead obstructions and electrical wires. Failure to do so may result in electrocution. Maintain at least 3 meters of clearance. Electrocution can occur without direct contact. Failure to do so may result in electrocution.

Step 2

Raise the auger only high enough to allow minimum clearance above the bin.

On Hydraulic Lift Undercarriage Models - Raise or lower the auger by using the hydraulic circuit control lever on the tractor.

TO RAISE THE AUGER WITH HAND WINCH: (FOR MANUAL LIFT MODELS)

Turn the handle clockwise (pulling cable onto winch drum). There should be a clicking sound.

NOTE: The winch is equipped with a brake that is actuated by turning the handle. The brake is designed to hold the load whenever the handle is released.

NOTE: Observe the cable as it is winding onto the winch drum. The cable should roll up on the drum evenly; avoid cable build-up on one side of the drum.



KEEP HANDS AWAY FROM WINCH DRUM DURING OPERATION.

Step 3

Back auger slowly into working position with a tractor. **NEVER MOVE AUGER BY HAND, USE A VEHICLE, DO NOT ATTEMPT TO INCREASE AUGER HEIGHT BY POSITIONING WHEELS ON LUMBER, BLOCKS OR BY OTHER MEANS.**

1. Lower the auger until the auger discharge is directly over the bin opening.
2. Once the auger is in place, put the tractor in park and the auger wheels should be chocked on both sides, so it will not roll when disconnected from the tractor.
3. Remove hitch pin or bolt from hitch clevis.

NOTE: When releasing from the tractor, test the intake end for downward weight. LOWER IT SLOWLY TO THE GROUND.

NOTE: Weight transfers rapidly to the head end if the intake is raised above the tow bar, particularly when the auger is in a raised position.

4. Remove bolt from hitch and remove hitch from auger intake.
5. If a plastic hopper is to be used, install at this time.
6. Lower the auger until the auger is directly over the bin opening.

NOTE: When discharging into a grain spreader, always maintain at least .3 m space between the auger discharge and the spreader.

7. On Hydraulic Lift Undercarriage Models - Close hydraulic shut-off valve to prevent lowering. Then disconnect hydraulic line from tractor.
8. The auger should be anchored at the intake end and/or supported at the discharge end. This will prevent auger from tipping when weight transfers to top end as auger empties. It is a good practice to tie the discharge end of the auger to the bin or grain storage structure to prevent possible wind damage. Remember to untie the auger before attempting to move.

DESIGNATED WORK AREA

Before starting the auger, a designated work area should be established and properly marked. The following diagrams will show the manufacturers designated work areas. These areas shall be marked off with colored nylon or plastic rope hung as portable barriers to define the designated work areas.

RULES FOR SAFE WORK AREA


Under no circumstances should persons not involved in the operation be allowed to trespass into the work area.




It shall be the duty of all operators to see that children and/or other persons stay out of the work areas! Trespass into the work area by anyone not involved in the actual operation, or trespass into a hazard area by anyone, shall result in an immediate shut down by the operator.

It shall be the responsibility of all operators to see that the work area has secure footing, is clean and free of all debris, and tools which might cause accidental tripping and/or falling. It shall also be their responsibility to keep the work area clean and orderly during the operation.

PTO DRIVE UNITS



ELECTRIC DRIVE UNITS



OPERATING PROCEDURES

START UP AND BREAK-IN INFORMATION

It is essential to inspect your drive before adding power and know how to shut down in an emergency.

During the operation of your auger, one person shall be in a position to monitor the operation. Any screw conveyor when it is new or after it sets idle for a season should go through a "break-in" period. The auger should be run at partial capacity until several hundred bushels of grain have been augered to polish the fighting assembly and tube. When the screw and tube are polished and smooth the auger can be run full.

Never operate the auger empty for any length of time as excessive wear will result. If at all possible do not stop or start the auger under load, especially before the flight and tube become well polished, as this may cause the auger to "freeze-up".

During the initial start up and break-in period, the operator shall be aware of any unusual vibrations or noises., that would indicate a need for service or repair.



Keep all safety shields and devices in place.

Keep hands, feet and clothing away from moving parts.

The operator should have a full view of the work area and check that all personnel are clear of designated work area before adding power.

Proper auger flight speed is important for efficient operation of the auger.

1. If the flight speed is in excess of what is recommended, excessive wear will result.
2. If the flight speed is slow and the auger fighting is permitted to "load-up", the high torque required to turn the auger fighting can damage the auger.

Be sure the drain hole cover on the intake guard is closed before start up.



SHUT OFF POWER AND LOCKOUT DRIVE TO ADJUST, SERVICE OR CLEAN.

DIRECT PTO DRIVE INFORMATION

The standard direct PTO may be driven from either side (as explained in the PTO Drive Assembly Section.)



Care should be taken when changing the drive from one side of the auger to the other side. To avoid dangerous situations, follow change over instructions on page 43.

1. The PTO driveline is equipped with a shear bolt at the tractor connection. The shear bolt protects the auger from damage if the auger becomes plugged or subjected to high loads. See page 13 for replacement shear bolt information.
2. To attach the PTO driveline to the tractor PTO start sliding the driveline end onto the PTO. Compress the spring keeper on the driveline and continue to slide onto the PTO until the keeper seats in the groove on the tractor PTO. Then the spring keeper will return to its original position and the PTO driveline will be locked onto the tractor PTO.

NOTICE: The PTO driveline furnished with the auger is equipped with a "Spring-Lok" coupler at the tractor end. This type coupler is spring loaded and will fit the standard 1 3/8" x 6" spline PTO output shaft from a tractor.

See that the PTO driveline is securely attached and the retaining balls of the "Spring-Lok" coupler lock into the ring groove of the tractor PTO output shaft. Check this by trying to pull the driveline off of the tractor PTO output shaft.

OPERATING PROCEDURES

DIRECT PTO DRIVE INFORMATION - CONT.

RECOMMENDED AUGER FLIGHT SPEED - FOR PTO POWERED AUGERS



The chart below shows the "Recommended Auger Flight Speed" in relationship to "Gearbox Input Shaft Speed". This gearbox input shaft speed can be regulated by the pulley sizes used on the electric motor or by the PTO speed of the tractor. NOTE: Use the tractor tachometer to determine the PTO speed which is the same as gearbox input shaft speed.

	MAXIMUM		MINIMUM	
AUGER DIA.	Gearbox Input Shaft Speed	= Flight Speed	Gearbox Input Shaft Speed	= Flight Speed
10"	540	= 540 RPM	300	= 300 RPM

The 10" model PTO powered auger uses a gearbox with a 1 to 1 drive ratio between the gearbox input shaft speed and the auger flight speed.

CHECK THE FOLLOWING BEFORE ADDING POWER:

1. Be certain the PTO driveline is securely attached to the auger and the tractor.
2. Never use a PTO driveline without a rotating shield in good working order that can be turned freely on the shaft.
3. Align PTO driveline with tractor. The PTO driveline furnished with the auger is a pin stop type—that is, the two telescoping sections will not separate. It is a good practice to operate the PTO driveline in as short a configuration as possible. Keep the PTO driveline in as straight a line as possible during operation. When connecting tractor and auger, always make sure the tractor axle and side of auger are parallel.
4. If the tractor and auger are on unlevel ground or at different levels, place them so the center line of the tractor and the gearbox shaft are parallel.



WHEN ADDING POWER:

The tractor operator should have a full view of the auger work area and check that all personnel are clear of hazard areas before adding power.

IMPORTANT: Engage PTO at a slow RPM to minimize shock loads. Then work up RPM to recommended speed.

OPERATING PROCEDURES - CONT.

TOP MOUNTED ELECTRIC MOTOR DRIVE INFORMATION

Always use a motor with required power suggested in the charts below. Use a motor that operates at 1750 RPM. Electric motors and controls shall be installed by a qualified electrician and must meet the standards set by the National Electrical Code and all local and state codes. Reset and Motor Starting Controls may be mounted directly to the auger or in a nearby area, but they must be located so that the operators have full view of the entire operation from the control location.

A magnetic starter should be used to protect your motor when starting and stopping. It should stop the motor in case of power interruption, conductor fault, low voltage, circuit interruption, or motor overload. Then the motor must be restarted manually. Some motors have built-in thermal overload protection. If this type motor is used, use only those with manual reset.

Auger Size	TPH (Max.)	Auger Pulley	Motor Pulley (Not Included)	Auger Speed	Minimum Power
10" x 32'	133	381 mm	114 mm O.D.	525 RPM	7.5-11 kw
10" x 42'					7.5-11 kw
10" x 52'					11-15 kw
10" x 62'					15-18.5 kw
10" x 72'					15-22 kw
10" x 32'	120	381 mm	102 mm O.D.	465 RPM	7.5-11 kw
10" x 42'					7.5-11 kw
10" x 52'					11-15 kw
10" x 62'					15-18.5 kw
10" x 72'					15-22 kw
10" x 32'	100	381 mm	89 mm O.D.	410 RPM	7.5 kw
10" x 42'					7.5-11 kw
10" x 52'					11 kw
10" x 62'					11-15 kw
10" x 72'					15-18.5 kw

OPERATING PROCEDURES - CONT.

TOP MOUNTED ELECTRIC MOTOR DRIVE INFORMATION

NOTE: Motor Pulleys are not furnished with the auger.

The power recommendations are for augering reasonably dry grain at varying angles. High moisture grain (above 15%) will require greater power. Maximum possible capacity will be less with high moisture grain than with dry grain.

Disconnect power before resetting motor overloads.
Make certain electric motors are grounded.

CHECK THE FOLLOWING BEFORE ADDING POWER:

1. Check that belt guard is in place, secured and functional.

TO START AUGER

1. Start electric motor before conveying grain.

TO STOP AUGER

1. Let auger empty of grain before stopping.
2. Shut off electric motor and lockout.

OPERATING CAPACITIES

Capacity ratings for 10" Augers are listed on page 10.

The results or capacities of screw conveyors or augers can vary greatly under varying conditions. Different materials, moisture content, amounts of foreign matter, angle of operation, methods of feeding and speed all play a role in the performance of the auger. An auger operating at a 45° incline could be cut 20% in capacity over an auger operating horizontally. Twenty-five (25%) moisture could cut capacity back by as much as 40% under some conditions. If an inclined auger has 30 centimeters of grain over the inlet flight it will probably get better capacity than if it had only a 3 centimeters covering. On the other hand, an auger in the bottom of a cone shaped pit or under a bulk tank with maybe 1 meter or more of grain on top of it may be overfed. This overfeeding would be caused from the weight of the grain over the intake forcing more into the auger than it can efficiently move. The result would be an increased power requirement, extra strain on the drive line, and possibly a complete stall out. In these situations, a baffle or lid should be used to limit grain access to the auger.

SHUTDOWN

A. NORMAL SHUTDOWN

When shutting down the auger, make certain that the hopper and auger are empty before stopping the unit. Before the operator leaves the work area, the power source shall be locked out. (See Lockout).

B. INTERMITTENT OPERATION SHUTDOWN

NOTE: When augers are stopped and restarted under full load, it may result in damage to the auger.

Consideration should be given to the proper size auger for a batch drying, or any intermittent type operations. Using a larger diameter auger and reducing its load level will be far better than subjecting a smaller diameter auger to high loads. If an auger is kept from absolute filling, it will make start-up easier and will convey more efficiently.

C. EMERGENCY SHUTDOWN

Should the auger be immediately shut down under load, disconnect and lockout the power source. Clear as much grain from hopper and auger as you can. Reconnect power source and clear auger. Never attempt to start when full.

NOTE: Starting the unit under load may result in damage to the auger. Such damage is considered abuse of the equipment.

OPERATING PROCEDURES - CONT.

LOCKOUT


If the operator must leave the work area, or whenever servicing or adjusting, the auger must be stopped and the power source turned off. Precaution should be made to prevent anyone from operating the auger when the operator is absent from the work area.

DIRECT PTO DRIVE: Remove ignition key or coil wire from power source. (If this is impossible, remove the PTO driveline from the work area.)

TOP MOUNTED ELECTRIC DRIVE: A main power disconnect switch capable of being locked only in the off position shall be provided.

RELOCATION OF AUGER

When grain conveying operation is completed, the auger should be moved away from the bin and lowered. The auger can then be moved to a different bin for more conveying operations or cleaned up and stored.



STEP 1

- A. Empty all grain from the auger. Clean up the area.
- B. Untie any anchors an/or remove all supports.
- C. Disconnect the power source.

Top Mounted Electric Drive - Unplug electric motor, wind up electric cables.

Direct PTO Drive - Disconnect PTO driveline from tractor and place in support provided for transporting.

NOTE: The bracket pin must be in place to hold the PTO driveline in the support during transporting.

- D. Install the hitch pipe.
- E. If the auger is to be stored or unused for a time, open drain hole cover on intake guard.
- F. On Hydraulic Lift Undercarriage Models
Connect the hydraulic hose to the tractor and open hydraulic shut-off valve.
- G. Raise the auger so the discharge spout is clear of bin opening. (See Auger Raising Instructions on page 6 for Manual Lift Models.)
- H. Lift the auger intake and hitch to the tractor. (See Hitching Instructions on page 4.)
- I. Remove wheel chocks.
- J. Move auger slowly away from the bin with a tractor — **NOT BY HAND.**

STEP 2

- A. Lower auger immediately after clear of bin or storage structure.

IMPORTANT: Lower the auger, even if relocating to a bin in the immediate area.

STEP 3

- A. Move the auger to next bin or the area where the auger is to be stored after use. We recommend that the auger be stored in the full down position with intake end anchored.
- B. On Hydraulic Lift Undercarriage Models:
Close hydraulic shut-off valve to prevent loss of hydraulic oil. Disconnect hydraulic hose from tractor.
- C. Unhitch auger from the tractor and lower auger intake to ground.
- D. Inspect the auger as outlined in the "Machine Inspection Section" on page 3.

LUBRICATION & MAINTENANCE

For economical and efficient operation of your auger maintain regular and correct lubrication. Neglect leads to reduced efficiency, excessive wear and needless down time.




Keep all safety shields and devices in place.
Never clean adjust or lubricate a machine that is in operation.

The following will detail the parts needing lubrication and the various conditions which determine the time span.

GEARBOX

Check and maintain oil level regularly. The unit must be level while performing this check. Remove the vented plug from the elbow. Oil is at the proper level when it is visible in the elbow. The use of SAE-80W-90 oil is recommended.

Care should be taken if the drive housing must be disassembled to repair or inspect the gearbox. **NOTE:** To avoid dangerous situations, follow Disassembly Instructions on page 43.



PTO DRIVELINE

Augers equipped with PTO driveline, should have the u-joints lubricated at approximately ten (10) hour intervals with SAE multipurpose type grease.



Before engaging P.T.O., be sure that PTO driveline shields turn freely on shaft.

The PTO driveline is equipped with a shear bolt at the tractor connection. The shear bolt protects the auger from damage if the auger becomes plugged or subjected to high loads. It is important to use the correct replacement bolt of the proper size and strength to insure that the shear device will protect the auger and operator. Order replacement shear bolt, Part No. 33046 - 5/16" - 18 x 1" long grade 5 bolt. Extra shear bolts are provided with auger.

BEARINGS


Intake Guard Bronze Bearing

Every auger has a bronze-with-graphite bearing at the intake end. This bearing requires no lubrication.

Undercarriage Axle Spindle Bearing

Tapered roller type bearings are standard on all 10" augers and should be repacked with grease and adjusted annually or as needed, determined by usage.

Care must be used in dismantling wheel bearing assemblies. First remove the dust cap by prying around the edges. Remove the cotter pin, slotted nut and flat washer. Carefully remove the hub and bearings from the spindle. Inspect all parts for wear or damage and replace with new ones, if necessary.



**TAPERED
ROLLER TYPE
BEARING ASSEMBLY**

When reassembling the hub, repack both bearing cones with grease and fill the hub cavity 1/3 full. Place inner bearing assemblies into the hub, and then press seal into hub and carefully reinstall the hub on the spindle. When placing hub on spindle be careful not to damage the lip of the grease seal. Install outer bearing assembly into the hub, and replace flat washer and slotted nut. Then tighten the slotted nut to seal the bearings until the hub binds as you rotate hub. Back off the slotted nut to the next slot and install a new cotter pin in. Use a 5/32" cotter pin 1 1/4" long. Replace dust cap.

BELT ADJUSTMENT

On drives that are powered by belts, the belt tension will need periodic adjustment. Use the adjustment bolts in the end of the motor mount. Turn equally. **DO NOT** overtighten.

LUBRICATION AND MAINTENANCE - CONT.

HYDRAULIC CYLINDER - On Hydraulic Lift Undercarriage Models

The hydraulic cylinder is equipped with an air breather in the rod end port. Check that the air breather is not plugged. Check the rod seals to see if they are leaking and replace damaged or leaking seals. Check to see if the cylinder is securely fastened to the lifting mounts.

HYDRAULIC HOSE - On Hydraulic Lift Undercarriage Models

Check the hydraulic hose and all the fittings to see if they are tight and not leaking hydraulic oil. Replace the hose if it is cut or damaged.



CAUTION: Do not connect or disconnect hydraulic components when there is pressure within the system. Hydraulic systems are highly pressurized. Escaping hydraulic oil, even an invisible pinhole leak, can penetrate body tissues and cause serious injury. Use a piece of wood or cardboard when looking for leaks. Never use the hands or other parts of the body. When reassembling, make absolutely certain that all connections are tight. If injured by hydraulic oil escaping under pressure, see a doctor immediately. Serious infection or reaction may occur if medical attention is not received at once.

BELT ADJUSTMENT

On drives that are powered by belts, the belt tension will need periodic adjustment.

WINCH INSTRUCTIONS - For Manual Lift Undercarriage Models

HAND WINCH OPERATION (FRICTION TYPE)

Check the handle assembly on your auger to determine that it has been assembled correctly. See assembly section. There should be a locknut attached to the end of the winch shaft to prevent inadvertent removal of the winch handle.

**Never fully extend the cable and always keep three complete turns of cable around winch drum.
Never operate winch with wet or oily hands and always use a firm grip on the handle.**



SAFETY REMINDERS

1. Operator must pay attention during raising and lower auger.
 - A. Watch cable to see if it is coiling properly onto winch drum evenly.
 - B. Keep hands away from winch drum during operation.
 - C. Don't use hands to guide cable onto winch drum during winch operation.
 - D. Don't allow auger to become hung up.
 - E. Don't continue to raise auger after slide reaches stop.

The following lubrication checks should be made to the winch periodically.

The auger should be in the lowered position with undercarriage lift arm slide against the upper head stop when this inspection is being performed. Refer to operating and maintenance instructions furnished with

your winch for proper inspection methods.

1. All gears should have a film of grease on them at all times.
2. The following parts must be wet with oil at all times:
 - A. Two bushings located at ends of drum shaft
 - B. The ratchet pawl pivot

IMPORTANT: Do not get oil or grease on brake disc faces (located between ratchet gear brake hub and pinion shaft.)

3. Check brake disc, if worn to less than 1.6 millimeter thick, cracked or broken, replace both discs.

(See the owner's manual and parts list for the winch that is included with this manual for additional winch information.)

FLIGHTING

See "Break-In Information" on page 8. Flighting should be "polished" each season or after an idle period.

TROUBLE SHOOTING

LOW CAPACITY

The auger may not be getting enough grain. Check to see the intake has not "bridged over" restricting the flow.

The exposed flighting at the auger intake should be covered with grain to achieve maximum capacity.

Check auger speed. A slow speed (below recommended speed) will result in low capacity. Refer to page 9 for Direct PTO Drive or page 10 for Top Mounted Electric Drive.

AUGER PLUGS

The auger may be getting too much grain and be "jamming" inside the housing. Reduce the amount of grain being fed into the auger.

On motor drive augers, the motor may be too small or wired improperly.

If wet grain or other hard to move material is being augered, use a larger size motor than recommended for normal use.

Is the auger free of any foreign material, such as sacks, tarp corners, etc? A plug of the discharge end will cause an auger plug.

On electric powered models, check to see that all belts are lined up and tensioned properly.

AUGER LOWERING BY ITSELF - On Hydraulic Lift Undercarriage Models

Check all hydraulic fittings, hose and connections for leaks. Check that the hydraulic shut-off valve is closed.

AUGER WILL NOT RAISE OR LOWER - On Hydraulic Lift Undercarriage Models

Check if hydraulic shut-off valve is open. See if the hydraulic coupler is properly attached to the tractor and the tractor reservoir is full of oil.

EXCESSIVE AUGER NOISE

Damage could have occurred to the auger flighting, thus causing noise. Damage usually occurs because of foreign material having been run through the auger. It may be necessary to remove the flighting for inspection. If this is to be done, consult Drive Housing Disassembly Instructions on page 43.

IMPORTANT: An auger should be frequently checked and serviced to operate freely. Keep all guards and shields in place. Replace any that are damaged or lost. An auger should be run partially full for several hundred bushels to polish the flighting when it has not been used for an extended period of time. An auger with flighting that has not been polished in this manner requires greater horsepower, and damage to the drive and/or flighting can result if overloaded.

Our augers are well made and we are proud of our line of equipment. We would like you, as our customer, to do your part in using caution and good judgement in using our equipment as well as any other machinery. Any parts needing replacement should be replaced with parts of the same type and size. Do not modify or alter any of the auger components.

ASSEMBLY INSTRUCTIONS

AUGER HOUSING LAYOUT

Choose an area on open level ground accessible to chain hoist or other lifting devices where the auger may be laid out full length. Lay the different sections of tube assemblies in the approximate positions. It will be convenient for assembly if the tubes are placed on stands or blocks so the drive housings are off the ground with the tubes level. **NOTE:** Orientate the 25'-6 1/2" tube sections so the decals are right side up and readable.




FIG. 1

GEARBOX AND DRIVE HOUSING ASSEMBLY

Step 1. Determine if you want the gearbox input shaft on the left or right side of the auger. The gearbox is shipped so the input shaft will be on the right side of the auger when assembled in the drive housing. PTO drives can be driven from either the right or left hand side of the auger. Fig. 3 on page 17 shows the gearbox in the right hand drive position. Electric drives can **ONLY** be powered from the right hand side. The gearbox **MUST** be mounted as shown in Fig. 3 on page 17. If you do decide to install the drive on the left side of the auger, the street el must be rotated so it is pointing up when installed into the drive housings.

Step 2. Add 1 liter of SAE 80W-90 oil to the gearbox. **IMPORTANT:** The gearbox is shipped without oil. The gearbox will be damaged if operated without oil. To add oil, remove oil filler plug in the elbow. Add oil and check oil level. Oil must be visible in the elbow when unit is on level ground.





FIG. 2

ASSEMBLY INSTRUCTIONS


GEARBOX AND DRIVE HOUSING ASSEMBLY (CONT.)



- Step 3. Connect the gearbox output shaft (with bevel) to the upper flight assembly using two 1/2" x 4" long (grade 8) hex head capscrews, four 1/2" rubber washers, four 1/2" washers and two stover type locknuts. Tighten the locknuts only enough to slightly compress the 1/2" x 1/4" thick rubber washers. **DO NOT** compress the washers more than 2 milliliters. Fig. 3.
- Step 4. Connect the lower flight to the gearbox lower output shaft using two 1/2" x 4" long (grade 8) hex head capscrews, four 1/2" rubber washers, four 1/2" washers and stover type locknuts.
- Step 5. Slide the notches in the drive housings over the gearbox mounting ears. Then bolt the drive housings to the gearbox mounting ears using eight 1/2" x 1" long (grade 5) hex head capscrews with lockwashers.
- Step 6. Bolt the drive housing flanges together using ten 1/2" x 1 1/4" long (grade 5) hex head capscrews and nylon locknuts.
- Step 7. Bolt the cover plate to the lower drive housing with 5/16" nylon locknuts.

IMPORTANT:

When bolting the flight sections to the gearbox, the orientation of the flight sections to each other is important for flight balance and smooth operation. The ends of the flight sections should be on the same side of the gearbox as shown in Fig. 4.



ASSEMBLY INSTRUCTIONS

FLIGHT SECTION ASSEMBLY

Bolt the upper sections of auger flight to the middle flight section, use two 1/2" x 3 1/2" long (grade 8) hex head capscrews and stover type locknuts (packaged separately). The middle section of flighting will overlap the upper section of flighting about one inch on the side toward the auger outlet. See Fig. 6.




FIG. 6

CONNECTING BAND CONNECTIONS

Slide head section and middle section of auger tubes together. Tighten auger tube connecting band using eight 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. Be sure auger tubes are tight together. About half of the band should be on each tube section. See Fig. 7.




FIG. 7

AUGER FLIGHT & HOUSING ASSEMBLY FOR UNITS WITH OPTIONAL INTERNAL FLIGHT BEARINGS (42', 52', 62' & 72')

- Step 1. Slide the connecting band onto the lower end of head auger section. (Bolts will be installed and tightened later.)
- Step 2. Slide an internal bearing hanger over the end of the flight connecting stub on the middle auger section. Then slide the flight sections out of head auger section so the lower end of those flight sections can be connected to the flight section extending out of the middle of the auger section. Use two 1/2" x 3 1/2" long (grade 8) hex head capscrews and stover type locknuts. (See Fig. 8.) The bearing hanger can be allowed to rotate downward.

BOTH ENDS OF THIS FLIGHT ARE INDEXED TO ACHIEVE TIMED CONNECTIONS FOR AUGERS WITH INTERNAL BEARINGS. (A TIMED CONNECTION IS WHERE THE FLIGHT PITCH DOES NOT CHANGE ACROSS THE CONNECTION.)

WHEN BOLTING TIMED FLIGHT SECTIONS TOGETHER AT THE INTERNAL FLIGHT BEARINGS, POSITION THE FLIGHT ENDS SO THEY ARE OPEN 90° TO 180° TO ONE ANOTHER.




FIG. 8

- Step 3. Slide the auger housing sections together so the tube ends are tight against each other. Position the connecting band with half of the band on each auger housing section. Tighten the connecting band down by using eight 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. (See Fig. 7.)
- Step 4. Use the bearing positioning bar provided to grab the internal bearing hanger stem through the housing slot to rotate the bearing hanger into its upward position.
 - A. Insert the double bended end of bearing positioning bar into slot and hook the internal bearing hanger stem. Rotate the bearing upward as much as possible. See Fig. 9A on page 19.
 - B. Remove the bearing positioning bar and insert the single bent end into slot. Hook the internal bearing hanger stem and by pulling upward, the internal bearing hanger will rotate upward. See Fig. 9B on page 19.

ASSEMBLY INSTRUCTIONS

AUGER FLIGHT & AUGER HOUSING SECTION ASSEMBLY FOR UNITS WITH OPTIONAL INTERNAL FLIGHT BEARINGS (42', 52', 62' & 72')




FIG. 9A




FIG. 9B

C. Attach the internal bearing hangers to the auger housing using a mounting plate, 5/8" x 1" long (grade 5) hex head capscrew and lockwasher per each hanger. See Fig. 10A. Before tightening the mounting bolts down, adjust the internal bearing hangers so they are centered between the ends of the auger flights. (See Fig. 10B.) This can be done by sliding the hanger back and forth in the slot to determine the approximate center.




FIG. 10A




FIG. 10B

BLOW-OFF CAP

- Step 1. Attach chain to the hole in the top of the tube, located at the discharge end of the auger using a 1/4" x 3/4" long hex head capscrew and 1/4" nylon locknut.
- Step 2. Attach the other end of the chain into the hole of the cap using a 1/4" x 3/4" long hex head capscrew and 1/4" nylon locknut.
- Step 3. Slide cap over end of tube. The cap should fit snugly, but be able to slide off the end of the tube if discharge should become plugged. Push the cap off to verify fit and then reinstall. It should be possible to tap the cap off by hand.




FIG. 11

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE MODELS

Pages 20 to 31 cover assembly for Manual Lift Undercarriage Models ONLY. If your auger has a hydraulic lift undercarriage, then go to page 32 for Track, Truss and Undercarriage Assembly.

Failure to locate components in the proper location will cause the undercarriage to fail and the auger to fail, resulting in property damage, personal injury or death.





FIG. 13

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE MODELS

! Failure to locate components in the proper location will cause the undercarriage to fail and the auger to fall, resulting in property damage, personal injury or death.

62' MODEL



72' MODEL




FIG. 14

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY - CONT.

See Fig. 13 on page 20 or Fig. 14 on page 21 for location of track, truss and undercarriage components.




IMPORTANT: The location of components that band to the auger tube is critical for proper operation of the undercarriage system. If the auger components you have do not match the lengths specified in these instructions or you cannot position the components where instructions specify due to interference with other items mounted on the auger tube, contact your dealer or the factory immediately. **DO NOT MODIFY** or **SUBSTITUTE** other components in an effort to complete the assembly of the auger.

Failure to position the components in the proper location will cause the undercarriage to fail and the auger to fall, resulting in property damage, personal injury or death.

TRACK AND RADIUS ROD CLAMP COMPONENTS

NOTE: On 32' models the spacer tube must be installed before track is fastened to the auger tube. See Detail C on page 20.

- Step 1. Band the track to auger tube by using plain 4" wide halfbands and four 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts per each band. When bolting the track to the auger tube, be sure to orientate so the bottom of the track is parallel with the center of gearbox input shaft. See Detail A on page 20.
- Step 2. Fasten spacer tube to collar at lower end of track with one 5/16" x 1 3/4" long (grade 5) hex head capscrew and nylon locknut.
- Step 3. On 42', 62', 62' & 72' fasten radius rod clamp to spacer tube with one 5/16" x 1 3/4" long (grade 5) hex head capscrew and nylon locknut. When bolting the radius rod clamp to the auger tube, be sure to orientate so the pivot tube and bottom of track are parallel. See Detail B on page 20.
- Step 4. On 42', 52', 62' & 72' fasten radius rod clamp to the auger tube using a 6" wide halfband and six 3/8" x 1 1/2" long hex head capscrews with nylon locknuts. On 42', 52', 62' and 72' the 6" wide halfband will have truss anchors welded to it. The truss anchors must be pointing towards the discharge end of the auger. See Fig. 20 on page 24 for 42', 52' & 62' models or Fig. 21 on page 24 for 72' models.
- Step 5. On 72' models bolt another lower cable truss to the auger tube just below the radius rods clamp. Use a 6" wide halfband and six 3/8" x 1 1/2" long (grade 5) hex head capscrews with nylon locknuts to secure lower truss anchor to auger tube. See Fig. 21 on page 24.



TRUSS COMPONENT ASSEMBLY FOR 42', 52', 62' AND 72' MODELS

See Fig. 13 on page 20 or Fig. 14 on page 21 for cable lengths, truss mount and cable anchor locations.

- Step 6. On 42', 52' and 72' models - Fasten the truss mount to the 6" wide half bands that are welded to the track. On the 42' model use four 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. On 52' and 72' models use six 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts.
- Step 7. Mount the upper truss cable anchors to auger tube using a 6" wide halfband and six 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. **NOTE:** The upper truss cable anchor is mounted on the under side of the tube. See Fig. 22 on page 24.
- Step 8. For 42', 52' & 62' Models, see instructions on top of page 23. For 72' Models, see instructions on bottom of page 23.

ASSEMBLY INSTRUCTIONS




TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY - CONT.

42', 52' & 62' MODELS ONLY

Step 8. Loosely bolt truss sides to truss mount.


Step 9. Bolt the crossbrace(s) between the truss sides with two 3/8" x 1 1/4" long (grade 5) hex head capscrews and nylon locknuts.

Step 10. Tighten the hardware holding truss sides to truss mounts.




TRUSS COMPONENT ASSEMBLY FOR 72' MODEL ONLY

Step 8. Loosely bolt the 39 1/2" and 30" long truss sides to the main truss mount on the track using 5/8" x 2" long (grade 5) hex head capscrew with nylon locknuts. See Fig. 18.



Step 9. Bolt the short cross brace between the 39 1/2" long truss sides using two 3/8" x 1 1/2" long (grade 5) hex head capscrew and nylon locknuts. Bolt the top cross brace between the truss sides and the vertical truss tubes using two 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. Bolt the other end of the vertical truss tube to the 30" truss sides using two 3/8" x 1 1/4" long (grade 5) hex head capscrews and nylon locknuts. See Fig. 18. Tighten the hardware holding the truss sides to the truss mount.

Step 10. Loosely bolt truss sides to upper truss mount. See Fig. 19. Bolt the crossbrace between the truss sides with two 3/8" x 1 1/4" long (grade 5) hex head capscrews and nylon locknuts. Tighten the hardware holding truss sides to truss mounts.



ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE - CONT.

TRUSS CABLE RIGGING FOR 42', 52', 62' & 71' MODELS

Step 11. Install the eyebolts into the lower truss anchor with the eye of the bolts pointing towards the discharge end of the auger. Install two nuts on each eyebolt. The 42', 52' and 62' models use two eyebolts. See Fig. 20. The 72' models use four eyebolts. See Fig. 21.




FIG. 20

**42', 52' & 62' MODEL
LOWER CABLE ANCHOR DETAIL**




FIG. 21

**72' MODEL
LOWER CABLE ANCHOR DETAIL**

Step 12. Attach truss cables to upper cable anchors using two cable clamps per each cable. **NOTE:** Secure the clamp u-bolts against the loose end of the cable.




FIG. 22

UPPER TRUSS CABLE ANCHOR


Step 13. Run the cables over the truss crossbrace, then towards the intake end of the auger. On 72' models use two sets of cables. The 51' (15.5 m) long set will run over the upper truss then over the main truss. A set of two 30'-0" (9.1 m) long cables will run over the main truss then towards the intake end of the auger.

ASSEMBLY INSTRUCTIONS


TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE - CONT.

TRUSS CABLE RIGGING FOR 42', 52', 62' & 72' MODELS - CONT.

- Step 14. Attach the cables to the truss sides. On 42', 52' and 62' models and the upper truss for 72' models, use 3/8" cable clamp to fasten the cables to truss sides. See Fig. 23. On the lower truss for 72' models, use a 3/8" u-bolt and two locknuts to hold two cables to the truss side. See Fig. 24.
IMPORTANT: DO NOT tighten the 3/8" clamps and 3/8" u-bolts at this time. The cables must be able to freely slide through the clamps or u-bolts while taking up the slack in step 16.



TRUSS CABLE TO TRUSS SIDE ON
42', 52' & 62' MODELS AND THE
UPPER TRUSS ON 72' MODELS




TRUSS CABLE TO TRUSS SIDE ON
LOWER TRUSS ON 72' MODELS

- Step 15. Attach truss cables to eyebolts using two cable clamps per each cable. **NOTE:** Secure the clamp u-bolt against loose end of cable. See Fig. 20. on page 24 for 42', 52' & 62' models. See Fig. 21 on page 24 for 72' models.
- Step 16. Using eyebolts tighten cables until they are reasonably snug. Tighten cables the equally. **DO NOT OVERTIGHTEN.** Sight down the tube to make sure all sections are straight. Some adjustment can be made after auger is completely set up.
- Step 17. Tighten the 3/8" cable clamps or 3/8" u-bolts holding the cable to the truss sides.

UNDERTRUSS CABLE RIGGING FOR 72' MODELS ONLY

Run the other set of 30'-0" (9.1 m) long cables so they will fasten to the 30" long truss side (hanging below track) using 3/8" cable clamps. See Fig. 25.

Attach the 30'-0" (9.1 m) long cables to eyebolts using two cable clamps per each cable. **NOTE:** Secure the clamp u-bolt against loose end of cable. See Fig. 21 on page 24. Using eyebolts tighten cables to remove slack to where the cables are reasonably snug. Tighten both cables the same. **DO NOT OVERTIGHTEN.** Sight down the tube to make sure all sections are straight. Some adjustments can be made after auger is completely set up. Tighten the 3/8" cable clamps or 3/8" u-bolts holding the cable to the truss sides.




ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE MODELS - CONT.


TRACK CABLE PULLEY AND CLEVIS COMPONENTS

Step 18. Assemble the cable pulley(s) to the short clevis. Then fasten clevis to anchor at lower end of track using 5/8" x 4" long (grade 5) hex head capscrew and nylon locknut.

32' & 42' MODELS




52', 62' & 72' MODELS




Step 19. Assemble pulley(s), spacer bushings, washers and cotter pin to long clevis.

32' & 42' MODELS



52', 62' & 72' MODELS




ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE - CONT.

RADIUS ROD AND AXLE LEG COMPONENTS


32', 42', 52' & 62' MODELS

FIG. 30



72' MODEL ONLY

FIG. 31



UNDERCARRIAGE COMPONENTS FOR MANUAL LIFT UNDERCARRIAGE

MODELS	32'	42'	52'	62'	72'
AXLE	73"	94 1/2"	94 1/2"	94 1/2"	120"
LENGTH "A"	(1.85m)	(2.4m)	(2.4m)	(2.4m)	(3.05m)
RADIUS ROD	77"	116"	146"	176 1/2"	209 1/4"
LENGTH "B"	(1.96m)	(2.95m)	(3.71m)	(4.48m)	(5.32m)
AXLE LEG	73 1/4"	126 1/2"	152"	178"	193"
LENGTH "C"	(1.86m)	(3.21m)	(3.86m)	(4.52m)	(4.9m)
CROSS PIPE	33"	53"	51"	49 3/4"	72 1/2"
LENGTH "D"	(.84m)	(1.35m)	(1.3m)	(1.26m)	(1.84m)

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE - CONT.

RADIUS ROD AND AXLE LEG COMPONENTS

See chart on page 27 to be sure that the undercarriage components are the correct length for the size of auger that is being assembled.

- Step 20. Lay out the radius rods (with trussing and square plate). The flattened ends of the radius rods must be toward the intake end of the auger. When standing at the intake end and facing the discharge end of the auger, the radius rod with the winch mount must be on the left side. See Fig. 30 or 31 on page 27.
- Step 21. Bolt the axle leg cross pipe to the axle legs with one 7/16" long (grade 5) hex head capscrew and nylon locknut in each end. On 32', 42', 52' & 62', models use 7/16" x 2" long (grade 5) hex head capscrew. On 72' models use 7/16" x 2 1/4" long (grade 5) hex head capscrew. Insert the short shafts on the axle legs into the square plates welded to the radius rods. Insert and spread one 5/16" x 2" cotter pin in the end of each short shaft.
- Step 22. On 72' models ONLY - fasten angle crossbraces between the axle legs. Secure angles to ears on axle legs with four 1/2" x 1 1/4" long (grade 5) hex head capscrews and nylon locknuts. **DO NOT** tighten hardware until trolley is assembled to axle legs in step 28. Bolt the middle of the angle crossbraces together using one 1/2" x 1" long (grade 5) hex head capscrew and nylon locknut. **DO NOT** tighten hardware until later.
- Step 23. Slide the axle shaft through the pipes on the ends of the radius rods.
- Step 24. The hubs, bearings, seals and spindles are assembled at the factory and are pressure packed with grease at that time. Slide the hub and spindle assembly into the undercarriage axle and secure with a hex head capscrew and nylon locknut. See chart A for bolt size.
- Step 25. Secure tire and rim to hub with lug bolts.
- Step 26. Lift the discharge end of the auger tube with adequate hoist, attaching it about 2/3 of the way from the intake end of the auger. Raise the discharge end of the tube assembly about 6'. Roll the undercarriage into position. Lift the axle legs and bolt trolley and trolley spacer with long clevis and pulley assembly together using 3/4" x 7" long (grade 5) hex head capscrew, flat washers and nylon locknut. See Fig. 32.

LENGTH	BOLT SIZE
32'	1/2" x 2 1/2" long
42', 52' & 62'	1/2" x 3 1/4" long
72'	1/2" x 3 3/4" long

**CHART A
SPINDLE BOLT SIZE**



IMPORTANT: The trolley must be assembled to the track in a manner whereby it cannot be removed from the track.




FIG. 32

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE - CONT.

RADIUS ROD AND AXLE LEG COMPONENTS - CONT.

Step 27. Slide the trolley along the track to the stop toward the discharge end. Lift the auger with the hoist high enough to line up the radius rods with radius rod clamp.

Step 28. Insert the pivot pipe spacer into the pipe on the radius rod clamp. Then, insert a 3/4" x 11" long (grade 5) hex head capscrew through a flat washer, one radius rod, a spacer and then the other radius rod and another flat washer and a nylon locknut. See Fig. 33.




FIG. 33

Step 29. Check to see all undercarriage bolts and fasteners are tight and assembled correctly. On 72' models tighten all the 1/2" hex head capscrews that fasten the angle crossbraces to axle legs in step 22.

Step 30. **Before releasing the hoist and with the intake on the ground, check the transport height of the auger (with the trolley touching the down stop) by measuring the distance from the top of the auger tube (at the discharge end) to the ground. Use the transport height chart on page 5 to check your measurement. If your measurement does NOT fit into the range on the chart for your size auger, then go back and check the following items:**

- A. Location of radius rod clamp and track - See page 20 and 21.
- B. The length of undercarriage components - See page 27.
- C. The length of auger tubes - See page 16.
- D. Is the discharge end of auger tube sagging because the truss cables require tightening - See step 16 on page 25.

If you have checked all of the above items and your measured discharged height is **NOT** in the range specified in the transport height chart, call your dealer or the factory immediately. **DO NOT CONTINUE TO ASSEMBLE THE AUGER** and do not release the hoist with the auger in this condition.

Step 31. When the height of the auger is correct as described in step no. 30 the hoist may be released.

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE MODELS - (CONT.)

WINCH AND CABLE COMPONENTS

Step 32. Hook clevis plates over anchor rod on left radius rod. Then assemble bushing, flat washers and cable pulley between the clevis plates using 1/2" x 2" long (grade 5) hex head capscrew and nylon locknut. After the locknut is tightened, check to see that the clevis plates are captured on the anchor rod and cannot come off. See Fig. 34.




FIG. 34

Step 33. Align slot of handle with flat portion of winch pinion shaft. Use hex nut to hold handle in place and tighten securely. For additional winch information, follow the instructions and precautions listed in the material supplied with the winch from the manufacturer. See Fig. 35.




FIG. 35

Step 34. Attach 1/4" lift cable to winch drum so cable will wrap over winch drum on 32' & 42' models and under winch drum for 52', 62' & 72' models when turning handle in a clockwise direction. See Fig. 36. From inside of drum, insert the cable through one round hole in the drum side, until it extends 3 cm past the two square holes. Next clamp the cable to the outside of the drum with the cable keeper, using two 3/16" x 3/4" carriage bolts, lock washers and nuts. Be sure that the carriage bolt heads are on the inside of the drum.




FIG. 36



CAUTION: The rope keeper alone will not hold the weight of the auger. There should be enough cable so that when the auger is all the way down there are at least 3 turns of cable on the winch drum. Never let the cable all the way out. Always keep a minimum of three (3) turns of cable on the winch drum. If there are not (3) turns of cable around the winch drum when the auger is fully lowered, then the cable must be replaced with a longer cable.

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR MANUAL LIFT UNDERCARRIAGE - CONT.

WINCH AND CABLE COMPONENTS

Step 35. Bolt winch assembly to mount left radius rod so the winch drum is towards the intake end of auger. Use three 3/8" x 1" long (grade 5) hex head capscrews, flat washers, and nylon locknuts to attach winch to mount. See Fig. 37.



Never fully extend the cable and always keep three complete turns of cable around winch drum.

Step 36. Rig the lift cable from the winch through the various pulleys and anchor to trolley. Different lengths of augers will require different rigging of the lift cable. See Fig. 38 for 32' & 42' models or Fig. 39 for 52', 62' and 72' models.

IMPORTANT: Secure lift cable to trolley with two cable clamps, with the clamp u-bolt against the loose end of the cable.

IMPORTANT: Do not disassemble pulley(s) from clevis(s) during rigging.







FIG. 37



RIGGING FOR 32' & 42' MODELS FIG. 38



BE SURE THE CABLE IS ON ALL CABLE PULLEYS BEFORE RAISING THE AUGER WITH THE WINCH.



RIGGING FOR 52', 62' & 72' MODELS FIG. 39


ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE MODELS - (CONT.)


Pages 32 to 39 cover assembly for Hydraulic Lift Undercarriage Models Only.

Failure to locate components in the proper location will cause the undercarriage to fail and the auger to fall, resulting in properly damage, personal injury or death.

52' MODEL



62' MODEL



72' MODEL




FIG. 40

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE MODEL - CONT.

See Fig. 40 on page 32 for location of track, truss and undercarriage components.



IMPORTANT: The location of components that band to the auger tube is critical for proper operation of the undercarriage system. If the auger components you have do not match the lengths specified in these instructions or you cannot position the components where instructions specify due to interference with other items mounted on the auger tube, contact your dealer or the factory immediately. **DO NOT MODIFY** or **SUBSTITUTE** other components in an effort to complete the assembly of the auger.

Failure to position the components in the proper location will cause the undercarriage to fail and the auger to fall, resulting in property damage, personal injury or death.

TRACK AND RADIUS ROD CLAMP COMPONENTS

Step 1. Band the track to auger tube. When bolting the track to the auger tube, be sure to orientate so the track pivot center line and gearbox input shaft center line are parallel. See Detail A on page 32.


52' Models - Use one 6" wide halfband at lower end and one 6" wide halfband with truss mount at the upper end.

62' Models - Use two 6" wide halfbands and four 4" wide bands.

72' Models - Use one 6" wide halfband and six 4" wide bands.

NOTE: Use six 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts to secure heavy duty halfbands to track. Use four 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts to secure 4" wide halfbands to track.

- Step 2. Fasten spacer tube to collar at lower end of track with one 5/16" x 1 3/4" long (grade 5) hex head capscrew and nylon locknut. See Detail C.
- Step 3. Fasten radius rod clamp to spacer tube with one 5/16" x 1 3/4" long (grade 5) hex head capscrew and nylon locknut. When bolting the radius rod clamp to the auger tube, be sure to orientate so the pivot tube and track pivot tube are parallel. See Detail B on page 32.
- Step 4. Fasten radius rod clamp to the auger tube using a 6" wide halfband and six 3/8" x 1 1/2" long (grade 5) hex head capscrews with nylon locknuts. On 52', 62' and 72' models the 6" wide halfband will have truss anchors welded to it. The truss anchors must be pointing towards the discharge end of the auger. See Fig. 43 on page 34 for 42' & 52' models. See Fig. 44 on page 34 for 72' models.
- Step 5. On 72' models bolt another lower cable truss to the auger tube just below the radius rods clamp. Use a 6" wide halfband and six 3/8" x 1 1/2" long (grade 5) hex head capscrews with nylon locknuts to secure lower truss anchor to auger tube.
- Step 6. On 72' models fasten the upper truss mount to the tube using a 6" wide halfband (with truss cable anchors welded to it) and six 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts.
- Step 7. Mount the upper truss cable anchors to auger tube using a 6" wide halfband and six 3/8" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. NOTE: The upper truss cable anchor is mounted on the under side of the tube. See Fig. 45 on page 34.
- Step 8. On 52' models fasten the undercarriage rest plates to the tube with a 4" wide halfband and four 3/8" x 1 1/2" (grade 5) hex head capscrews and nylon locknuts. See Fig. 40 on page 32 for location.



ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE - CONT.

TRUSS COMPONENTS

See Fig. 40 on page 32 cable lengths, truss mounts and cable anchor locations.

Step 9. Loosely bolt truss sides to truss mount.

Step 10. Bolt the crossbrace(s) between the truss sides with two 3/8" x 1 1/4" long (grade 5) hex head capscrews and nylon locknuts.

Step 11. Tighten the hardware holding truss sides to truss mounts.




FIG. 41

52' MODEL MAIN TRUSS
72' MODEL UPPER TRUSS




FIG. 42

62' MODEL MAIN TRUSS
72' MODEL LOWER TRUSS

TRUSS CABLE RIGGING

Step 12. Install the eyebolts into the lower truss anchor with the eye of the bolts pointing towards the discharge end of the auger. Install flat washer and two nuts on each eyebolt. The 52' and 62' models use two eyebolts. See Fig. 43. The 72' models use four eyebolts. See Fig. 44.




FIG. 43

52' & 62' MODEL
LOWER CABLE ANCHOR DETAIL




FIG. 44

72' MODEL
LOWER CABLE ANCHOR DETAIL

Step 13. Attach truss cables to upper cable anchors using two cable clamps per each cable. NOTE: Secure the clamp u-bolts against the loose end of the cable. See Fig. 45.

Step 14. Run the cables over the truss crossbraces, the towards the intake end of the auger. (The 72' models use two sets of cable. The long set will run over the upper truss then over the main truss. The short set of cables will run over the main truss then towards the intake end of auger.)




FIG. 45


UPPER TRUSS CABLE ANCHOR DETAIL

ASSEMBLY INSTRUCTIONS


TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE MODELS - CONT.

TRUSS CABLE RIGGING - CONT.

- Step 15. Attach the cables to the truss sides. On 52' and 62' models and the upper truss for 72' models, use 3/8" cable clamp to fasten the cables to truss sides. See Fig. 46. On the lower truss for 72' models, use a 3/8" u-bolt and two locknuts to hold two cables to the truss side. See Fig. 47.
- IMPORTANT: DO NOT** tighten the 3/8" clamps and 3/8" u-bolts at this time. The cables must be able to freely slide through the clamps or u-bolts while taking up the slack in step 17.



**TRUSS CABLE TO TRUSS SIDE ON
52' & 62' MODELS AND THE
UPPER TRUSS ON 72' MODELS**



**TRUSS CABLE TO TRUSS SIDE ON
LOWER TRUSS ON 72' MODELS**

- Step 16. Attach truss cables to eyebolts using two cable clamps per each cable. **NOTE:** Secure the clamp u-bolt against loose end of cable. See Fig. 43 on page 34 for 52' & 62' models. See Fig. 44 on page 34 for 72' models.
- Step 17. Using eyebolts tighten cables until they are reasonably snug. Tighten both cables the same. **DO NOT OVERTIGHTEN.** Sight down the tube to make sure all sections are straight. Some adjustment can be made after auger is completely set up.
- Step 18. Tighten the 3/8" cable clamps or 3/8" u-bolts holding the cable to the truss sides.


RADIUS ROD AND UNDERCARRIAGE FRAME COMPONENTS

See chart on page 36 to be sure that the undercarriage components are the correct length for the size of auger that is being assembled.

- Step 19. Lay out the radius rods (with trussing and square plate). The flattened ends of the radius rods must be toward the intake end of the auger. When standing at the intake end and facing the discharge end of the auger, the radius rod with the winch mount must be on the left side. See Fig. 48 on page 36. Lay the undercarriage frame between the radius rods.
- Step 20. Insert the pivot shaft on the undercarriage frame into the square plates welded to the radius rods. Insert and spread one 5/16" x 2" cotter pin in each pivot shaft to secure in place.
- Step 21. Slide the axle shaft through the pipes on the ends of the radius rods. The hubs, bearings, seals and spindles are assembled at the factory and are pressure packed with grease at that time. Slide the hub and spindle assembly into the undercarriage axle and secure with a hex head capscrew and nylon locknut. Models 52' & 62' use 1/2" x 3 1/4" long (grade 5) hex head capscrew and model 72' uses 1/2" x 3 3/4" long (grade 5) hex head capscrew.
- Step 22. Secure tire and rim to hub with lug bolts.

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE MODELS - (CONT.)



UNDERCARRIAGE COMPONENTS

Model	52'	62'	72'
A - Axle Length	94 1/2" (2.4 m)	94 1/2" (2.4 m)	120" (3.05 m)
B - Radius Rod Length	146" (3.71 m)	176 1/2" (4.48 m)	209 1/4" (5.32 m)
C - Undercarriage Frame	88 1/2" (2.25 m)	102 3/4" (2.61 m)	115" (2.92 m)
D - H-Frame Center to Center of Holes	19 1/4" (.49 m)	19 1/4" (.49 m)	26 5/8" (.68 m)
E - H-Frame Tubes (Overall Length)	64 1/2" (1.64 m)	82 1/2" (2.1 m)	97" (2.46 m)
F - Cylinder Size	4" Bore x 24" Stroke	4" Bore x 24" Stroke	4" Bore x 36" Stroke

NOTE A:

After Step 27 wrap a chain or heavy strap around the tube and undercarriage. Chain or strap must be tight to keep undercarriage from opening when the tube is raised so the radius rods can be connected to the radius rod clamp.

FIG. 48

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE - CONT.

RADIUS ROD AND UNDERCARRIAGE FRAME COMPONENTS - CONT.

- Step 23. Lift the discharge end of the auger tube with adequate hoist, attaching it about 2/3 of the way from the intake end of the auger. Raise the tube about 6'. Roll the undercarriage into position under the auger tube.
- Step 24. Insert the pivot spacer bushing into track pivot (welded at the lower end of the track).
- Step 25. Lift the upper undercarriage frame legs and bolt the "H" frame and upper legs to the track pivot using a 1" x 11" long (grade 5) hex head capscrew and nylon locknut on 52' & 62' models or 1" x 12" long (grade 5) hex head capscrew and nylon locknut on 72' models.
- Step 26. Bolt the "H" frame tubes to the lower end of the "H" frame with 3/4" x 2" long (grade 5) hex head capscrews and nylon locknuts.
- Step 27. Fasten the other end of "H" frame tubes to the ears on the undercarriage crosstube with 3/4" x 2" long (grade 5) hex head capscrews and nylon locknuts.
- Step 28. Wrap a chain or heavy duty strap around the auger tube and undercarriage frame. Chain or strap must be tight to keep the undercarriage from opening when the tube is raised to connect the radius rods to radius rod clamp. See Fig. 48 on page 36.
- Step 29. Lift the auger with the hoist high enough to line up the radius rods with radius rod clamp.
- Step 30. Insert the pivot pipe spacer into the pipe on the radius rod clamp. Then insert a 3/4" x 11" long (grade 5) hex head capscrew through a flat washer, one radius rod, a spacer and then the other radius rod and a nylon locknut. See Fig. 50. **NOTE:** Check to see all undercarriage bolts and fasteners are tight and assembled correctly.
- Step 31. Before releasing the hoist and with the intake on the ground, check the transport height of the auger in full down transport position (with the trolley touching the down stop) by measuring the distance from the top of the auger tube (at the discharge end) to the ground. Use the transport height chart on page 5 to check your measurement. If your measurement does **NOT** fit into the range on the chart for your size auger, then go back and check the following items:

- Location of radius rod clamp and track - See page 32.
- The length of undercarriage components - See page 36.
- The length of auger tubes - See page 16.
- Is the discharge end of auger tube sagging because the truss cables require tightening - See step 17 on page 35.

If you have checked all of the above items and your measured discharged height is **NOT** in the range specified in the transport height chart, call your dealer or the factory immediately. **DO NOT CONTINUE TO ASSEMBLE THE AUGER** and do not release the hoist with the auger in this condition.

- Step 32. When the height of the auger is correct as described in step 31, the hoist may be released.




FIG. 49

TURN "H" FRAME SO CYLINDER MOUNTING EAR POINTS TOWARD AUGER DISCHARGE END. SEE FIG. 51 ON PAGE 38.




FIG. 50

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE MODELS (CONT.)


Step 33. Attach the hydraulic cylinder to the "H" frame using mounting pin and keeper clip furnished in box with cylinder.

IMPORTANT: The base end of the cylinder must be attached to mount on the track. The rod end of the cylinder will be attached to the mount on the "H" frame. The cylinder ports must be facing the left side of the auger when viewing the auger from the intake end.

IMPORTANT: The cylinder furnished with your auger has a restrictor in the port at the base end of the cylinder. This restrictor limits the speed the auger is raised or lowered. Only use cylinder provided with auger. Do not use a cylinder that does not have the proper restrictor.

HYDRAULIC HOSE COMPONENTS

Step 34. Thread the heavy duty street el into the upper cylinder port at the base). See Fig. 51. Tighten and leave street el parallel with auger tube and pointed toward inlet. Attach the swivel end of the hydraulic hose to street el and tighten.



Step 35. Starting at the cylinder end of the hose, fasten the hydraulic hose to the tube housing using hose mounting clamp. The mounting clamps are attached to various halfbands along the tube. See Fig. 52 on page 39 for the location of the hose clamps.

Step 36. Thread the shut-off valve onto the end of the hose. When installed, the arrow on the valve must point towards the auger and away from the tractor. The hose should be threaded into the female end of the valve.

Step 37. Check all fittings and connections to see if tight.



CAUTION: Do not connect or disconnect hydraulic components when there is pressure within the system. Hydraulic systems are highly pressurized. Escaping hydraulic oil, even an invisible pinhole leak, can penetrate body tissues and cause serious injury. Use a piece of wood or cardboard when looking for leaks. Never use the hands or other parts of the body. When reassembling, make absolutely certain that all connections are tight. If injured by hydraulic oil escaping under pressure, see a doctor immediately. Serious infection or reaction may occur if medical attention is not received at once.

Step 38. Fasten the hydraulic hose holder to drive housing using to 1/2" x 1 1/4" long (grade 5) hex head capscrew and lockwasher. See Fig. 53 on page 39.

ASSEMBLY INSTRUCTIONS

TRACK, TRUSS AND UNDERCARRIAGE ASSEMBLY FOR HYDRAULIC LIFT UNDERCARRIAGE MODELS - (CONT.)

HYDRAULIC HOSE COMPONENTS

HYDRAULIC HOSE CLAMP LOCATIONS








FIG. 52

*NOTE: 2" WIDE HALFBANDS ARE SECURED TO TUBE BY USING (TWO) 5/16" x 1 1/2" LONG (GRADE 5) HEX HEAD CAPSCREWS AND NYLON LOCKNUTS

ASSEMBLY INSTRUCTIONS

ELECTRIC MOTOR DRIVE ASSEMBLY

- Step 1. Fasten front end of motor mount frame to drive housing flange with four 1/2" x 1 1/2" long hex head capscrews (grade 5) and nylon locknuts.
- Step 2. Attach back end of motor mount frame to auger tube with a 6" wide halfband and six 5/16" x 1 1/2" long hex head capscrews (grade 5) and nylon locknuts.
- Step 3. Fasten belt guard bracket to drive housing flange with two 1/2" x 1 1/2" long hex head capscrews (grade 5) and nylon locknuts.
- Step 4. Bolt belt guard to brackets on motor mount frame with four 5/16" x 1" long hex head capscrews (grade 5), flat washers and nylon locknuts.



ASSEMBLY INSTRUCTIONS

ELECTRIC MOTOR DRIVE ASSEMBLY - CONT.

- Step 5. Bolt belt guard to belt guard bracket that is bolted to drive housing. Use two 5/16" x 3/4" long (grade 5) hex head capscrews, flat washers and nylon locknuts.
- Step 6. Install required size of electric motor. See chart on page 10 for horsepower recommendations. **IMPORTANT:** Use the proper size and speed motor to ensure satisfactory conveyor operation. Too small of a motor will not supply the horsepower required to achieve capacity and possible damage to the motor will occur. Too large of a motor may cause high stress on conveyor components resulting in shorter life for those components.
- Step 7. Install 4.5" (114 mm) O.D. pulley on motor shaft (motor pulley not furnished).
- Step 8. Install 15" (381 mm) O.D. pulley onto gearbox input shaft with 1/4" square drive key. **NOTE:** 62' and 72' models use tapered lock Q.D. bushing to secure pulley to gearbox shaft. **NOTE:** Tighten setscrews in hub to secure pulley to gearbox shaft.
- Step 9. Align pulleys by using a straight edge, placed across the outer faces of both pulleys. Install and tighten belts. Use the adjustment bolts in the end of the motor mount. Adjustment bolts should be turned equally to prevent binding.
- DO NOT** over tighten belts or excessive wear or damage will occur.

P.T.O. DRIVE ASSEMBLY

The PTO driveline is equipped with a shear bolt at the tractor connection. The shear bolt protects the auger from damage if the auger becomes plugged or subjected to high loads. It is important to use the correct replacement bolt of the proper size and strength to insure that the shear device will protect the auger and operator.


Order replacement shear bolt, Part No. 33046 - 5/16" - 18 x 1" long Grade 5 bolt. Extra shear bolts are provided with auger.

NOTE: P.T.O. drives can be driven from either the right or left hand side of the auger.



Care should be taken when changing drive from one side of the auger to the other side. To avoid dangerous situations, follow changeover instructions on page 43.

- Step 1. Attach PTO driveline to gearbox input shaft by using 1/4" x 1 1/2" long square drive key. See Fig. 55. Secure PTO driveline to gearbox shaft by tightening setscrews in PTO driveline yoke. See Fig. 56 on page 42.



ASSEMBLY INSTRUCTIONS

PTO DRIVE ASSEMBLY - CONT.

IMPORTANT: For setscrew to be properly engaged on the gearbox input shaft, the gearbox input shaft **MUST** be slid into the PTO driveline yoke until the setscrew will sit on flat portion of shaft. (See Fig 56.) Do not extend the gearbox input shaft beyond the inside end of the yoke.




FIG. 56

- Step 2. Remove two 1/2" x 1"-long (grade 5) hex head capscrew that hold gearbox mounting ear to drive housing.
- Step 3. Slide input shield over the PTO driveline and fasten to the drive housing using two 1/2" x 1 1/4" long (grade 5) hex head capscrews with lockwashers. See Fig. 55 on page 41.

NOTE: Locate the slit in the rubber on the input shield so the PTO driveline can be swung towards the discharge end of the auger.

- Step 4. Place the PTO driveline support 51" from the center of the gearbox (on the discharge end of the drive housing). Secure that support to the tube with a halfband and two 5/16" x 1 1/2" long (grade 5) hex head capscrews and nylon locknuts. See Fig. 57.

IMPORTANT: Do not install the support where the bands will cover any safety signs on the auger housing.

- Step 5. Install the retaining pin by slipping the short bend end of pin through hole in PTO driveline support and through slot on the other side. Allow long end of pin to rotate down, this will secure pin in place.
- Step 6. Set PTO driveline into the support to be sure the support is installed properly.




FIG. 57

DRIVE HOUSING DISASSEMBLY INSTRUCTIONS

Care should be taken if the drive housing must be disassembled to repair the gearbox and flight or to change drive from one side of the auger to the other side of the auger.

- Step 1. Disconnect power source from the auger.
- Step 2. Auger must be in full down transport position.
On Manual Lift Models - The trolley seated against the down stop.
On Hydraulic Lift Models - The auger tube seated on the undercarriage crossbrace.
- Step 3. Support the discharge end of auger, either with overhead hoist to hold the auger up or a suitable structure under the auger.
- Step 4. Block just above the drive housing so the intake end is 4" to 6" above the ground.
- Step 5. Disassemble drive housing halves to gain access to gearbox and flight. On electric drive models, the auger sheaves, belts and belt guard must be removed before drive housings can be disassembled.
- Step 6. **IMPORTANT:** Be sure the auger is completely reassembled before removing any supports.




FIG. 58

PTO DRIVE CHANGEOVER INSTRUCTIONS

- Step 1. Disconnect PTO driveline from tractor.
- Step 2. Remove the input shield from drive housing.
- Step 3. Follow the above drive housing disassembly instructions, so gearbox can be unbolted from the drive housing halves.
- Step 4. Slide the drive housing apart so gearbox can be rotated 180°.
- Step 5. The filler/vent elbow on the gearbox mounting ear must be rotated so it is pointing up.
- Step 6. Bolt gearbox to drive housing halves and the drive housing flanges together.
- Step 7. Install the input shield to cover the PTO driveline to gearbox shaft connection. See Fig. 55 on page 41.
- Step 8. Remount the PTO driveline support onto the other side of the tube. See Fig. 57 on page 42.

ASSEMBLY INSTRUCTIONS

HITCH TO INTAKE

Attach hitch to tube attachment anchor with one 1/2" x 3 1/2" long (grade 5), hex head capscrew, lockwasher and nut. See Fig. 59.




FIG. 59

OPERATOR'S MANUAL CONTAINER

1. Check that an Operator's Manual is in the plastic container.
2. Snap the container into holder located on the left radius rod arm.




FIG. 60

OPERATOR'S MANUAL CONTAINER
Snaps into holder located on inside of the left radius rod.

TO DEALER/ASSEMBLER NOTICE

The assembly of the auger is complete if all the applicable assembly steps in this manual have been followed.


Before delivery to the owner it is a good practice to check the following:

- a. Be sure all safety shields and devices are installed properly.
- b. Check all safety decals to see if they are clean and readable. If any are missing, damaged, painted over, etc. replace them. See page P-1 & P-2 for safety sign location. Decals may be obtained from your dealer or ordered from the factory.
- c. Check all bolts and fasteners to see they are tightened and secured properly.
- d. Check that the Operator's Manual container (with Operator's Manual inside) is installed in its holder located on the left radius rod.

Deliver this Assembly and Operator's Manual to the owner along with the auger.

10" INLINE/MID-DRIVE





SAFETY SIGNS AND DECALS



REF.	PART NO.	DESCRIPTION	SIZE
1	1025077	CAUTION - GENERAL	88 mm x 168 mm
2	1024078	DANGER - POWER LINES	88 mm x 168 mm
3	1025079	DANGER - UPENDING HAZARD	88 mm x 168 mm
4	1025080	DANGER - ROTATING AUGER	88 mm x 168 mm
5	1025081	DANGER - ROTATING DRIVE LINE	88 mm x 168 mm
6	1025083	WARNING - ESCAPING HYDRAULIC OIL	88 mm x 168 mm
7	1004461	OPERATOR'S MANUAL INSIDE	38 mm x 190 mm

10" INLINE/MID-DRIVE


SAFETY SIGNS AND DECALS



10" INLINE/MID-DRIVE

MAIN AUGER COMPONENTS FOR MANUAL LIFT UNDERCARRIAGE UNITS


NOTE: Reference letters designate detail views shown on page P-8.



10" INLINE/MID-DRIVE

MAIN AUGER COMPONENTS FOR HYDRAULIC LIFT UNDERCARRIAGE UNITS

Note: Reference letters designate detail views shown on page P-8.



10" INLINE/MID-DRIVE

MAIN AUGER COMPONENTS

(Parts listed below are shown on pages P-3 & P-4)

MAYRATH HOUSINGS - (Galv. 14 ga. wall)

REF. NO.	PART NO.	DESCRIPTION
1	1013260CE	Tube Housing - Lower w/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018053CE-120	f/42', 52', 62' & 72' (25' long)
	1018054CE-120	f/52' w/Corn Screens (25' long)
	1018055CE-120	f/62' w/Corn Screens (25' long)
3	1004811	Tube Housing - Middle f/72' (20' long)
4-7	---	Tube Housing - Upper
4	1018065CE-320	f/32' (25'-0" long)
5	1008363	f/42' (10'-0" long)
6	1008364	f/52' & 72' (20'-0" long)
7	1008365	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

HUTCHINSON HOUSINGS - (Galv. 14 ga. wall)

REF. NO.	PART NO.	DESCRIPTION
1	1013260CE	Tube Housing - Lower w/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018053CE-120	f/42', 52', 62' & 72' (25' long)
	1018054CE-120	f/52' w/Corn Screens (25' long)
	1018055CE-120	f/62' w/Corn Screens (25' long)
3	1004811	Tube Housing - Middle f/72' (20' long)
4-7	---	Tube Housing - Upper
4	1018065CE-220	f/32' (25'-0" long)
5	1012243	f/42' (10'-0" long)
6	1012244	f/52' & 72' (20'-0" long)
7	1012245	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

MAYRATH HOUSINGS - (Galv. 14 ga. wall) FOR INTERMEDIATE BEARINGS

REF. NO.	PART NO.	DESCRIPTION
1	1013260CE	Tube Housing - Lower w/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018056CE-120	f/42', 52', 62', 72' (25' long)
	1018058CE-120	f/52' w/Corn Screens (25' long)
	1018059CE-120	f/62' w/Corn Screens (25' long)
	1018057CE-120	f/72' w/I.B. (25' long)
3	1012931-120	Tube Housing - Middle f/72' only
4-7	---	Tube Housing - Upper
4	1018066CE-320	f/32' (25'-0" long)
5	1013664-320	f/42' (10'-0" long)
6	1012932-320	f/52' & 72' (20'-0" long)
7	1013877-320	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

HUTCHINSON HOUSINGS (Galv. 14 ga. wall) FOR INTERMEDIATE BEARINGS

REF. NO.	PART NO.	DESCRIPTION
1	1013260CE	Tube Housing- Lower f/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018056CE-120	f/42', 52', 62', 72' (25' long)
	1018058CE-120	f/52' w/Corn Screens (25' long)
	1018059CE-120	f/62' w/Corn Screens (25' long)
	1018057CE-120	f/72' w/I.B. (25' long)
3	1012931-120	Tube housing - Middle f/72' only
4-7	---	Tube Housing - Upper
4	1018066CE-220	f/32' (25'-0" long)
5	1013664-220	f/42' (10'-0" long)
6	1012932-220	f/52' & 72' (20'-0" long)
7	1013877-220	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

NOTE: See following page for 12 ga. wall (Heavy duty) housings.

10" INLINE/MID-DRIVE

MAIN AUGER COMPONENTS

(Parts listed below are shown on pages P-3 & P-4.)

MAYRATH HOUSINGS - (Galv. 12 ga. wall)

REF. NO.	PART NO.	DESCRIPTION
1	1015689CE	Tube Housing - Lower w/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018053CE-130	f/42', 52', 62' & 72' (25' long)
	1018054CE-130	f/52' w/Corn Screens (25' long)
	1018055CE-130	f/62' w/Corn Screens (25' long)
3	1014675-130	Tube Housing - Middle f/72' (20' long)
4-7	---	Tube Housing - Upper
4	1018065CE-330	f/32' (25'-0" long)
5	1014454-330	f/42' (10'-0" long)
6	1014676-330	f/52' & 72' (20'-0" long)
7	1014872-330	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

HUTCHINSON HOUSINGS - (Galv. 12 ga. wall)

REF. NO.	PART NO.	DESCRIPTION
1	1015689CE	Tube Housing - Lower w/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018053CE-130	f/42', 52', 62' & 72' (25' long)
	1018054CE-130	f/52' w/Corn Screens (25' long)
	1018055CE-130	f/62' w/Corn Screens (25' long)
3	1014675-130	Tube Housing - Middle f/72' (20' long)
4-7	---	Tube Housing - Upper
4	1018065CE-230	f/32' (25'-0" long)
5	1014454-230	f/42' (10'-0" long)
6	1014676-230	f/52' & 72' (20'-0" long)
7	1014872-230	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

MAYRATH HOUSINGS - (Galv. 12 ga. wall) FOR INTERMEDIATE BEARINGS

REF. NO.	PART NO.	DESCRIPTION
1	1015689CE	Tube Housing - Lower w/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018056CE-130	f/42', 52', 62', 72' (25' long)
	1018058CE-130	f/52' w/Corn Screens (25' long)
	1018059CE-130	f/62' w/Corn Screens (25' long)
	1018057CE-130	f/72' w/l.B. (25' long)
3	1012931-130	Tube Housing - Middle f/72' only
4-7	---	Tube Housing - Upper
4	1018066CE-330	f/32' (25'-0" long)
5	1013664-330	f/42' (10'-0" long)
6	1012932-330	f/52' & 72' (20'-0" long)
7	1013877-330	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'


HUTCHINSON HOUSINGS - (Galv. 12 ga. wall) FOR INTERMEDIATE BEARINGS

REF. NO.	PART NO.	DESCRIPTION
1	1015689CE	Tube Housing - Lower f/Intake Guard
--	8379C	Bronze Bushing (1 1/4" Bore)
2	---	Tube Housing - Center
	1018056CE-130	f/42', 52', 62', 72' (25' long)
	1018058CE-130	f/52' w/Corn Screens (25' long)
	1018059CE-130	f/62' w/Corn Screens (25' long)
	1018057CE-130	f/72' w/l.B. (25' long)
3	1012931-130	Tube Housing - Middle f/72' only
4-7	---	Tube Housing - Upper
4	1018066CE-230	f/32' (25'-0" long)
5	1013664-230	f/42' (10'-0" long)
6	1012932-230	f/52' & 72' (20'-0" long)
7	1013877-230	f/62' (30'-0" long)
7A	1018015	Upper Drive Housing
	1018064	Upper Drive Housing f/32'

NOTE: See previous page for 14 ga. wall (standard) housings.

MISCELLANEOUS COMPONENTS

REF. NO.	PART NO.	DESCRIPTION
8	1012D	Connecting Band - 30" long
9	1008112	Blow-off Cap
10	1007758	Chain for Blow-off Cap
11	1030834	Hitch Pipe
12	1012921	Gearbox Housing Cover Plate
13	1013526	Drain Hole Cover
--	1004287	Manual Container



10" INLINE/MID-DRIVE

MAIN AUGER COMPONENTS


(Parts listed below are shown on pages P-3 & P-4.)

FLIGHT SECTIONS

REF. NO.	PART NO.	DESCRIPTION
15-18	---	Flight - Upper
15	1013122	f/32' (23'-6 1/4" long) 7 ga.
	1013309	f/32' (23'-6 1/4" long) 1/4"
16	1013123	f/42' (8'-4 1/2" long) 7 ga.
	1013310	f/42' (8'-4 1/2" long) 1/4"
17	1013124	f/52' & 72' (18'-4 1/2" long) 7 ga.
	1013311	f/52' & 72' (18'-4 1/2" long) 1/4"
18	1013125	f/62' (28'-4 1/2" long) 7 ga.
	1013312	f/62' (28'-4 1/2" long) (1/4")
19-20	---	Flight - Center
19	1013120	f/42', 52', 62' & 72' (25'-2" long) 7 ga.
	1013307	f/42', 52', 62' & 72' (25'-2" long) 1/4"
20	1013121	f/72' (20'-0" long) 7 ga.
	1013308	f/72' (20'-0" long) 1/4"
21	---	Flight - Lower
	1013113	f/All (5'-1" long) 1/4"
	1014704	f/All (5'-1" long) 3/8"

FLIGHT SECTIONS FOR OPTIONAL INTERNAL BEARINGS

REF. NO.	PART NO.	DESCRIPTION
21	1013113	Flight Lower (5'-2 1/2" long) 1/4"
	1014704	Flight Lower (5'-2 1/2" long) 3/8"
22	1012265	Flight Upper (4'-9 1/4" long) 7 ga.
	1012267	Flight Upper (4'-9 1/4" long) 1/4"
23	1011320	Flight Intermediate (9'-9 3/4" long) 7 ga.
	1011779	Flight Intermediate (9'-9 3/4" long) 1/4"
24	1013434	Flight Middle (8'-4 1/2" long) 7 ga.
	1013439	Flight Middle (8'-4 1/2" long) 1/4"




MISCELLANEOUS FLIGHT COMPONENTS

REF. NO.	PART NO.	DESCRIPTION
26	1011165	Connecting Stub, Weld-in
27	1013126	Weld-in Intake Stub
28	1009504	Connecting Bolt 1/2" x 3 1/2" long (Grade 8)
29	1011182	1/2" Stover Type Locknut
--	40057	Intake Repair Flight 9" O.D. x 3/8" thick x 2' long (single flight)

OPTIONAL INTERNAL BEARING COMPONENTS

REF. NO.	PART NO.	DESCRIPTION
30	4010A91	Internal Bearing Hanger w/Bronze Bushing
--	1051D	Replacement Bronze Bushing Only
31	1012296	Mounting Plate
--	1012298	Bearing Positioning Bar
32	--	5/8" x 1 1/2" Grade 5 Hex Head Capscrew
33	1011167	Connecting Stub, Weld-in
34	1012569	Head Stub, Weld-in



GEARBOX FLIGHT CONNECTION COMPONENTS


REF. NO.	PART NO.	DESCRIPTION
80	1022512	1/2" x 4" long (Grade 8)
81	33025	1/2" Plate Washer
82	1022475	1/2" Rubber Washer
83	1011182	1/2" Stove Typ. Locknut
84	1012888	10" In-Line Gearbox

MAIN AUGER COMPONENTS


(Some parts listed below are shown on pages P-3 & P-4.)

TRACK & TRUSS COMPONENTS


REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
35	1007900	Upper Band-on Truss Anchor	60-64	---	Track f/Manual Lift Models
36-37	---	Truss Mount	60	1008084	f/32' (6'-11 1/4" long)
36	1008114	f/42' Main Truss	61	1008085	f/42' (11'-1" long)
37	1007807	f/52' Main & 72' Upper Truss	62	1013220	f/52' (14'-0" long)
38-40	---	Truss Side Straps	63	1013237	f/62' (14'-6" long)
38	106380	f/42' Main Truss (19" long)	64	1013242	f/72' (20'-1 1/2" long)
39	106399	f/52' Main & 72' Upper Truss (32" long)	65-67	---	Track f/Hydraulic Lift Models
40	1007847	f/62' & 72' Main Truss (39 1/2" long)	65	1008089	f/52' (4'-4 3/4" long)
41-43	---	Truss Crossbrace	66	1013245	f/62' (12'-0" long)
41	106381	f/42' Main Truss (21-1/2" long)	67	1013258	f/72' (19'-6 5/8" long)
42	106398	f/52', 62' & 72' Main Truss (top) (28" long)	68	5930A1	Halfband, 4" wide galv.
43	1008523	f/62' & 72' Main Truss (bottom) (19 5/8" long)	69	106207-1	Halfband, 6" wide painted
44-50	---	Truss Cable	70-75	---	Spacer Tube
44	1013226	f/42' (1/4" x 27' long)	70	1008527	23 7/8" long (f/32' Manual Lift)
45	1002055	f/52' (1/4" x 36' long)	71	1013218	80 3/4" long (f/42' Manual Lift)
46	1007896	f/62' (5/16" x 43' long)	72	1008575	97 3/4" long (f/52' Manual Lift)
47	1007892	f/72' w/Manual Lift (5/16" x 30' long)	73	1013243	105" long (f/72' Manual & 52' Hyd. Lift)
48	862027	f/72' (5/16" x 31') Undertruss	74	1013259	117 1/4" long (f/62' Hyd. Lift)
49	1013424	f/72' w/Hydraulic Lift (5/16" x 32' long)	75	1013239	124 1/2" long (f/62' Manual Lift)
50	1007897	f/72' (5/16" x 51' long)	76	1007762	Rest Plate f/52' (f/Hyd. Lift)
51	866015-1	Eyebolt 5/8" Dia.	77	1012783	Rest Plate f/72' (f/Hyd. Lift)
52	6369C	Cable Clamp - 1/4"	78	1008108	Radius Rod Clamp f/42', 52' & 62'
53	3153A91	Cable Clamp - 5/16"	79	1008552	Radius Rod Clamp f/72' (Manual Lift only)
54	3010L11	Cable Clamp - 3/8"			
55	4841	U-Bolt - 3/8" f/72' Main Truss			
56	1008110	Lower Band-on Truss Anchor			
57	1008111	Lower Band-on Truss Anchor (f/72')			
58	1008508	Undertruss Side Strap 30" long (f/72' only)			
59	1008507	Truss Vertical Tube 56 5/8" long (f/72' only)			




DETAIL A




DETAIL B




DETAIL E



DETAIL C



DETAIL D



DETAIL F

02448A1-B

02449A1-B

02870A1-A

02450A1-B


02506A1-B

02868A1

1031874-P8

10" INLINE/MID-DRIVE

MANUAL LIFT MODEL UNDERCARRIAGE COMPONENTS




02877A1

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	**	Radius Rod Clamp	11	1007711	Trolley Spacer Bushing 4 3/4" long
2	1006164	Radius Rod Spacer Tube (8 1/4" long)	12	33214	Bolt 3/4" x 7" long HHCS (grade 5)
3	835058	Bolt 3/4" x 11" long HHCS	13	1007712	Trolley Pulley Clevis
4	---	Axle	14	1007713	Pulley Clevis Bushing (1 5/8" long)
	1007694	f/32' (73" long)	15	1008195	1/4" Cable Pulley (3.0" O.D.)
	1006100	f/42', 52' (94 1/2" long)	16	1007757	10 Ga. Washer (2 1/8" O.D. x 1 1/8" I.D.)
	1014653	f/62' (93" long)			
	1007329	f/72' (120" long)	17	---	Track Pulley Clevis
5	---	Right Radius Rod		1008196	f/32' & 42'
	1008518	f/32' (6'-5" long)		1007754	f/52', 62' & 72'
	1007626	f/42' (9'-8" long)	18	---	Track Pulley Clevis Bushing
	1007446	f/52' (12'-2" long)		1008197	f/32' & 42' (5/8" long)
	1014699	f/62' (14'-8 3/4" long)		1007713	f/52', 62' & 72' (1 5/8" long)
	1007330	f/72' (17'-5 1/4" long)	19	1007890	Pulley Straps for Radius Rod
6	---	Left Radius Rod w/Winch Mount	20	1008197	Cable Pulley Bushing (5/8" long)
	1008517CE	f/32' (6'-5" long)	21	---	Lift Cable
	1007627CE	f/42' (9'-8" long)		1003819	f/32' (1/4" x 28' long)
	1007447CE	f/52' (12'-2" long)		1002573	f/42' (1/4" x 44' long)
	1014700CE	f/62' (14'-8 3/4" long)		8396C	f/52' (1/4" x 82' long)
	1007331CE	f/72' (17'-5 1/4" long)		1008539	f/62' (1/4" x 88' long)
7	---	Axle Leg Tube		1007891	f/72' (1/4" x 118' long)
	1008516	f/32' (33" long)	22	6369C	Cable Clamp - 1/4"
	1007703	f/42' (53" long)	23	3335A11	K-1550 Winch (32' & 42' Models)
	1007704	f/52' (51" long)	23	40301	K-2550 Winch (52', 62' & 72' Models)
	1007469	f/62' (49 3/4" long)	24	1001562	Spindle and Hub Assembly 4-bolt (1.62 O.D. Spindle) f/32' Models (See Page P-10 for parts breakdown.)
	1007840	f/72' (72 1/2" long)			
8	---	Axle Leg	24	1001563	Spindle and Hub Assembly 4-bolt (2.062 O.D. Spindle) f/42', 52', 62' & 72' Models (See Page P-10 for parts breakdown.)
	1008519	f/32' (6'-1" long)			
	1007707	f/42' (10'-6 1/2" long)	25	6393D	Wheel Rim (4-Bolt)
	1007449	f/52' (12'-8" long)			
	1007860	f/62' (14'-0" long)			
	1007861	f/72' (16'-1" long)			
9	1007841	Cross Brace Angles			
10	1007753	Trolley (with Steel Rollers)			

**Listed on page P-8.

10" INLINE/MID DRIVE

SPINDLE & HUB ASSEMBLIES




REF NO.	DESCRIPTION	4-BOLT	4-BOLT
		(1 5/8" x 10") f/10" x 32'	(2 1/16" x 10") f/10" x 42', 52', 62' & 72'
—	Spindle & Hub Assy.	1001562	1001563
1	Spindle	1001001	1001002
2	Grease Seal	106245	106245
3	Inner Cone (Timken No.)	3079R1 (LM67048)	3079R1 (LM67048)
4	Inner Cup (Timken No.)	3148R1 (LM67010)	3148R1 (LM67010)
5	Hub **	90174	90174
6	Outer Cup (Timken No.)	40552 (LM11910)	40552 (LM11910)
7	Outer Cone (Timken No.)	40551 (LM11949)	40551 (LM11949)
8	Lug Bolt	106241	106241
9	Washer	106252	106252
10	Slotted Hex Nut (5/8")	106250	106250
11	Cotter Pin (5/32" x 1 1/4")	D1146	D1146
12	Hub Cap	106244	106244

** Furnished with Cups.

HYDRAULIC LIFT MODEL
UNDERCARRIAGE COMPONENTS

52', 62' & 72' MODELS ONLY




REF NO.	PART. NO.	DESCRIPTION	REF NO.	PART. NO.	DESCRIPTION
1	**	Track	11	---	"H" Frame to Undercarriage Frame Tube
2	**	Halfband	1007796		f/52' (64" long)
3	**	Spacer Tube	1007864		f/62' (82" long)
4	---	Axle	1007865		f/72' (96 1/2" long)
	1006100	f/52' (94 1/2" long)	12	---	Hydraulic Cylinder
	1014653	f/62' (93" long)			(See following page for parts breakdown)
	1007329	f/72' (120" long)	1004368-1		f/52' & 62' (4" Bore x 24" Stroke)
5	---	Right Radius Rod	1004369-1		f/72' (4" Bore x 36" Stroke)
	1007446	f/52' (12'-2" long)	13	106413	90° Street El (1/2" Pipe)
	1014699	f/62' (14'-8 3/4" long)	14	---	3/8" Dia. Hydraulic Hose
	1007330	f/72' (17'-5 1/4" long)	1007944		f/52' (29'-0" long)
6	---	Left Radius Rod	1013268		f/62' (34'-6" long)
	1007447CE	f/52' (12'-2" long)	1013269		f/72' (39'-0" long)
	1014700CE	f/62' (14'-8 3/4" long)	15	1005886	Ball Valve (1/2" Pipe)
	1007331CE	f/72' (17'-5 1/4" long)	16	1007735	Hose Carrier Bracket
7	---	Undercarriage Frame	17	1006324	Hose Clamp
	1007686	f/52'	18	5035A1	Halfband 2" wide (for Hose Clamps)
	1007687	f/62'	19	1001563	Spindle and Hub Assembly 4-Bolt
	1007688	f/72'			(See Page P-10 for parts breakdown.)
8	---	"H" Frame Weldment	20	6393D	Wheel Rim (4-Bolt)
	1007689	f/52' & 62'	21	**	Rest Plate
	1007690	f/72'	22	**	Half Band for Rest Plate
9	---	Spacer Tube f/H-Frame	23	835058	Bolt 3/4" x 11" long HHCS
	1007939	f/52' & 62' (8 1/4" long)	24	**	Radius Rod Clamp
	1007940	f/72' (9 1/4" long)	25	1006164	Radius Rod Spacer Tube (8 1/4" long)
10	---	H-Frame Bolt			
	1007941	f/52' & 62' (1" x 11" long)			
	1007942	f/72' (1" x 12" long)			
—	1007943	1" Nylon Locknut			

** This part is listed on page P-8.

10" INLINE/MID-DRIVE

Page P-12

HYDRAULIC CYLINDER



4" BORE x 24" STROKE
 COMPLETE NO. 1004368-1
 USED ON 8" x 52'
 & 10" x 52'


4" BORE x 36" STROKE
 COMPLETE NO. 1004369-1
 USED ON 8" x 62' & 72'

REF. NO.	DESCRIPTION	HUTCHINSON/		HUTCHINSON/	
		MAYRATH PART NO.	MONARCH PART NO.	MAYRATH PART NO.	MONARCH PART NO.
1	Rod Clevis	1028822	492652	1028822	492652
2	Clevis Pin	1028823	134953	1028823	134953
3	Clevis Pin Clip	1028824	134952	1028824	134952
4	Port Adapter	1028825	642643	1028825	642643
5	Breather	1028826	110559	1028826	110559
6	*End Cap O-Ring	Seal Kit #1028827		Seal Kit #1028828	
7	*Piston O-Ring				
8	*Rod O-Ring				
9	*Rod Wiper Seal				
10	*End Cap Back-up Washers	Seal Kit #1028828		Seal Kit #1028828	
11	*Piston Back-up Washers				
12	*Rod Seal Back-up Washers				

*Only available as part of Seal Kit.

10" INLINE/MID-DRIVE

PTO DRIVE COMPONENTS




REF. NO.	PART NO.	DESCRIPTION
1	1024028	PTO Driveline (See parts breakdown on next page.)
2	8371C	Key 1/4" x 1 1/2" long
3	1008107	PTO Driveline to Auger Shield
4	3338A1	Transport Keeper Pin
5	1003212	PTO Driveline Transport Bracket
6	5035A1	Halfband 2" wide
7	---	Gearbox (See gearbox information on page P-15.)
8	1025611	Chain Attach Bracket

10" INLINE / MID DRIVE

PARTS LIST

PTO DRIVELINE COMPONENTS



NOTE: Repair parts for PTO drivelines can also be purchased directly from:

Weasler Engineering, Inc.
 P.O. Box 558
 West Bend, WI 53095

COMPLETE DRIVELINE - 1024078

U-JOINT TYPE - 14R
 AUGER END 1 1/4" BORE
 WITH 1/4" KEYSEAT
 TRACTOR END 1 3/8 - 6B SPLINE
 WITH SHEAR BOLT

REF. NO	DESCRIPTION	HUTCHINSON/ MAYRATH PART NO.	WEASLER PART NO.
1	Spring Lock Flange Repair Kit	26-10070	26-10070
2	End Yoke	14121-1010	14121-1010
3	U-Joint Cross Repair Kit	40524	03-10134
4	CE Warning Decal	13-14891	13-14891
5	Chain Kit	19-15083	19-15083
6	Non-Rotating Guard Repair Kit	19-15086	19-15086
7	Outer Safety Sign	13-10021	13-10021
8	CE Guard Label	13-15139	1315139
9	Outer Guard	97-21372	97-21372
10	Inner Guard	96-21372	96-21372
11	Safety Sign (not shown)	13-10022	13-10022
12	Yoke & Ball Shear Assembly	40-40016	40-40016
13	Shear Bolt & Nut Kit (See Note)	1004778	--
14	.375 - 16 x .38 long Setscrew	33170	11-10215
15	.375 - 16 x .50 long Setscrew	11-11035	11-11035


Note: Shear Bolt Kit includes (6) 5/16" - 18 x 1" long Grade 5 hex bolts and locknuts.

10" INLINE/MID-DRIVE

GEARBOX (Complete Part No. 1012888-1)

1 1/4" DIA. INPUT SHAFT
1 1/2" DIA. OUTPUT SHAFTS

RATIO 1 TO 1



HUTCHINSON/


REF. NO	QTY.	WEASLER PART NO.	MAYRATH PART NO.	DESCRIPTION
1	2	71-20019	035439	1 1/2" Cone (Timken No. LM29749)
2	2	71-20016	035440	1 1/2" Cup (Timken No. LM29710)
3	2	71-20022	837045	1 1/4" Cone (Timken No. 15126)
4	2	71-20023	106323	1 1/4" Cup (Timken No. 15245)
5	4	71-40015	1030165	Seal 2" x 1 1/2" O.D.
6	1	71-40018	1030166	Seal 1 1/4" x 2 7/16" O.D.
7	1	72-40017	837030	Key 1/4" x 1/4" x 1 1/8"
8	1	72-40002	1002276	Key 3/8" x 3/8" x 1" long
9	2	71-60011	1032006	Snap Ring
10	1	71-60002	003538	Snap Ring
11	1	71-50016	1027835	Spacer
12	1	72-20013	035930	3/4" Vent Plug
13	1	--	035931	Elbow
--	2	*72-20002	*020009	1/4" Drain Plug

*Indicates parts not shown.

10" INLINE/MID-DRIVE

Page P-16

ELECTRIC DRIVE COMPONENTS



REF. NO.	PART NO.	DESCRIPTION
1	1012888	Gearbox (See previous page for parts breakdown)
2	1013182	Motor Mount Frame
3	106225	10" Half Band (6" wide)
4	1013211	Belt Guard Weldment
5	1013181	Mounting Bracket f/Belt Guard
6	40161	15" Sheave 3B 1 1/4" Bore f/32', 42' & 52' Models
6	3092A1	15" Sheave 4B QD Bore f/62' & 72' Models
--	3072A1	1 1/4" Bore SK QD Bushing f/4B 15" Sheave
7	4045A1	Square Key 1/4" x 2" long
8	40125	B-68 Belt f/32', 42' & 52' Models
8	40126	B-71 Belt f/62' & 72' Models



Hutchinson/Mayrath

A Division of **GLOBAL** *Industries, Inc.*

P.O. Box 629 514 W. Crawford Clay Center, KS 67432
Phone 785-632-2161 1-800-523-6993 FAX 785-632-5964